# **Civil Aviation Authority of Bangladesh**

# Gazette

Dhaka, ৯ই অগ্রহায়ণ, ১৪৩২ /26 November, 2025

File No: CAAB 30.31.0000.116.43.002.23 – In exercise of the power conferred by Section 47, read with Section 14 of the Civil Aviation Act, 2017 (Act No. 18 of 2017), hereinafter referred as the "Act", the Chairman of the Civil Aviation Authority of Bangladesh is pleased to issue this **Amendment -1** to Air Navigation Order (ANO) ANO 14 VOL-I, Issue-1.

2. **This Amendment-1** to ANO 14 VOL-I, Issue-1 shall come into force with immediate effect.

Air Vice Marshal Md Mostafa Mahmood Siddiq BSP, GUP, ndc, afwc, acsc, psc

Chairman

Civil Aviation Authority of Bangladesh

# INTRODUCTION

#### 1.1 Short Title and Commencement

The ANO under reference No: CAAB 30.31.0000.116.43.002.23 which was published on 20 March 2024 through gazette notification (pages 15583 to 15946) is called as "Air Navigation Order on Aerodrome Design and Operations shortly ANO 14 VOL-I, Issue -1 became effective from the date as mentioned in the ANO.

This ANO will be called as Amendment-1 to ANO 14 VOL-I, Issue-1 on Aerodrome Design and Operations issued in accordance with Amendment 18 to Annex 14 VOL-I to the Convention on International Civil Aviation. This ANO shall be referred to herein as **Amendment-1** to ANO 14 VOL-I, Issue-1.

This **Amendment-1** to ANO 14 VOL-I, Issue-1 shall be the integral part of ANO 14 VOL-I, Issue-1 and shall be effective immediately upon published in this Official Gazette.

#### 1.2 Explanation

The whole document ANO 14 VOL-I, Issue-1 and its amendment-1 contain the Provisions in accordance with the Annex 14 Vol 1 (up to 18th amendment) to the Chicago Convention on Aerodrome Design and Operations.

#### 1.3 Control of ANO 14 VOL-I and its Review Process

- a) ANO 14 VOL-I and its amendment document are the property of the Civil Aviation Authority of Bangladesh.
- b) The ANO 14 VOL-I is under the full authority of the Chairman, Civil Aviation Authority of Bangladesh. Member (Flight Standard & Regulations) of CAAB is the custodian of the ANO 14 VOL-I.
- c) Member (Flight Standard & Regulations) is responsible for revision, distribution, retention, and processing of the approval of the ANO 14 VOL-I.
- d) This ANO will be reviewed: -
  - after changes or amendment of ICAO Annex 14 V-1; after changes of other Annexes which dictate to change ANO 14 VOL-I;
  - if necessary, after changes of Act, Laws, Rules etc relating to aviation;
  - if there are any mistakes/errors in the document and perform reviews as and when it deems necessary;
- e) After reviewing, if it becomes necessary to review the existing provision or any portion of a provision of this ANO, it will be reflected through the issuance of amendment.
- f) If the amendment requires more than 50% of pages to be updated/changed, it is recommended that a complete issue of the document be published, with new issue number and issue date, with the issue number incremented by I (one) with the previous issue number.
- g) After approval and gazette notification, ANO will be published in the CAAB website for the use of the stakeholders.

# 1.4 Dispute Resolution

a) Should there be any confusion of understanding of the content(s) of this ANO 14 VOL-I and its amendment, the matter should be brought to the attention of the Member (Flight Standard & Regulations) of CAAB for clarification.

b) In the circumstances, when any dispute or contradiction arises for compliance with the provisions of the ANO 14 VOL-I and which cannot be resolved through the existing provisions of the ANO, the final decision lies with the Member (Flight Standard & Regulations) of CAAB. However, Member (Flight Standard & Regulations) of CAAB may submit the issue before the Chairman, CAAB, if deemed necessary.

# 1.5 NOTES ON THE PRESENTATION OF THE AMENDMENT-1 TO ANO 14, VOL- I, Issue-1

The text of the amendment is arranged to show deleted text with a line through it and new text highlighted with grey shading, as shown below:

Text to be deleted is shown with a line through it. text deleted

New text to be inserted is highlighted with grey shading. new text inserted

Text to be deleted is shown with a line through it—followed by the replacement text which is highlighted with grey shading.

modified,- meaning existing text replaced by new text

**1.6** Amendment to ANO 14 VOL-I has been given Chapter by Chapter.

Note: Those amendments for which applicable date is not mentioned, will be applicable from 27 Nov' 2025.

# **CHAPTER 1. GENERAL**

# 1.2.2 **Definitions**

# Following Definition has been inserted, -

*Ground handling.* Services necessary for an aircraft's arrival at, and departure from, an airport, other than air traffic services.

# 1.2.3 Abbreviations

# Following Abbreviations have been inserted,-

ADG	Aeroplane design group
GBAS GHSP GSE	Ground-based augmentation system Ground handling service provider Ground support equipment
• • •	
OES	Obstacle evaluation surfaces
•••	
OFS	Obstacle free surfaces
• • •	
RDRS	Runway distance remaining sign
•••	
SBAS	Satellite-based augmentation system
•••	
ULD	Unit load device
•••	
$V_{at}$	Indicated airspeed at threshold
Vso	Stalling speed or the minimum steady flight speed in the landing configuration
Vs1g	Stalling speed or the minimum steady flight speed in a specified configuration

**Table 1-1.** Aerodrome reference code (see 1.6.2 to 1.6.4)

Code element 1					
Code number	Aeroplane reference field length				
1	Less than 800 m				
2	800 m up to but not including 1 200 m				
3	1 200 m up to but not including 1 800 m				
4	1 800 m and over				
Code element 2					
Code letter	Wingspan				
A	Up to but not including 15 m				
В	15 m up to but not including 24 m				
C	24 m up to but not including 36 m				
D	36 m up to but not including 52 m				
E	52 m up to but not including 65 m				
F	65 m up to but not including 80 m				

# 1.8 Aeroplane Design Group

(Applicable as of 21 November 2030)

Note.— The intent of the Aeroplane Design Group (ADG) is to provide a method for interrelating the specifications for the management of obstacles around aerodromes. The ADG utilizes two criteria related to the aeroplane performance characteristics and dimensions. The first criterion is based on the indicated airspeed of the aircraft at threshold and the second criterion on the aeroplane wingspan.

See Chapter 4 on the application of ADG for the provisions of obstacle restriction and removal.

- 1.8.1 An ADG shall be determined for each runway in accordance with the characteristics of the critical aeroplane for which the runway is intended.
- 1.8.2 The ADG shall be determined from Table 1-2, by selecting the ADG corresponding to the highest values of indicated airspeed at threshold and wingspan of the aeroplanes for which the runway is intended.

Note.— Indicated airspeed at threshold ( $V_{at}$ ) is equal to the stall speed Vso multiplied by 1.3, or stall speed Vs1g multiplied by 1.23 in the landing configuration at the maximum certificated landing mass. If both Vso and Vs1g are available, the higher resulting  $V_{at}$  applies.

# **Table 1-2. Aeroplane Design Group** (see 1.8.2)

(Applicable as of 21 November 2030)

Aeroplane Design Group	Indicated airspeed at threshold		Wingspan
I	Less than 169 km/h (91 kt)	and	Up to but not including 24 m
IIA	Less than 169 km/h (91 kt)	and	24 m up to but not including 36 m
ПВ	169 km/h (91 kt) up to but not including 224 km/h (121 kt)	and	Up to but not including 36 m
пс	224 km/h (121 kt) up to but not including 307 km/h (166 kt)	and	Up to but not including 36 m
Ш	Less than 307 km/h (166 kt)	and	36 m up to but not including 52 m
IV	Less than 307 km/h (166 kt)	and	52 m up to but not including 65 m
V	Less than 307 km/h (166 kt)	and	65 m up to but not including 80 m

Note 1.— Detailed specifications concerning the application of the aeroplane design group are given in the Airport Services Manual, Part 6 — Control of Obstacles (Doc 9137).

Note 2.— The following examples illustrate how the ADG is determined.

Example 1.— If the critical aeroplane that the runway is intended to serve has an indicated airspeed at threshold of 161 km/h (87 kt) and a wingspan of 20 m, then the aeroplane design group would be I.

*Example 2.*— If the critical aeroplane that the runway is intended to serve has an indicated airspeed at threshold of 224 km/h (121 kt) and a wingspan of 52 m, then the aeroplane design group would be IV.

# **CHAPTER 2**

# Section 2.12: letter chronology of sub paragraphs has been modified.

# 2.12 Visual approach slope indicator systems

The following information concerning a visual approach slope indicator system installation shall be made available: a) associated runway designation number;

- b) type of system according to 5.3.5.2. For PAPI or APAPI installation, the side of the runway on which the lights are installed, i.e. left or right, shall be given;
- c) where the axis of the system is not parallel to the runway centre line, the angle of displacement and the direction of displacement, i.e. left or right, shall be indicated;
- -e d) nominal approach slope angle(s). For a PAPI and an APAPI this shall be angle  $(B + C) \div 2$  and  $(A + B) \div 2$ , respectively as in Figure 5-20; and
- -d e) minimum eye height(s) over the threshold of the on-slope signal(s). For a PAPI this shall be the setting angle of the third unit from the runway minus 2′, i.e. angle B minus 2′, and for an APAPI this shall be the setting angle of the unit farther from the runway minus 2′, i.e. angle A minus 2′.

# CHAPTER 3. PHYSICAL CHARACTERISTICS

Sections 3.4.5; 3.4.9;3.4.18 & 3.11.4 and Table 3-1 &Table 3-2 of Chapter 3 of ANO 14 VOL-I have been modified.

Section 3.5.12: Serial numbers of referred articles have been modified from 9.2.34 & 9.2.35 to 9.2.33 & 9.2.34 respectfully.

Validity of existing section 3.12.9 is up to 20 Nov 2030. As of 21 Nov2030 a new text for section 3.12.9 has been inserted.

A new section 3.13.2 has been inserted and existing sections 3.13.2 & 3.13.6(a) have been modified and sections 3.13.2 to 3.13.6 have been renumbered as 3.13.3 to 3.13.7 respectfully.

# 3.4 Runway strips

. ..

- 3.4.5 A strip including a non-instrument runway shall extend on each side of the centre line of the runway and its extended centre line throughout the length of the strip, to a distance of at least:
- -75 m where the code number is  $\frac{3}{9}$  or  $\frac{4}{3}$ ;
- 55 m where the code number is 3;
- 40 m where the code number is 2; and
- 30 m where the code number is 1.

# Grading of runway strips

- 3.4.9 That portion of a strip of a non-instrument runway within a distance of at least:
- -75 m where the code number is  $\frac{3}{2}$  or  $\frac{4}{3}$ ;
- 55 m where the code number is 3;
- 40 m where the code number is 2; and
- 30 m where the code number is 1;

from the centre line of the runway and its extended centre line shall provide a graded area for aeroplanes which the runway is intended to serve in the event of an aeroplane running off the runway.

. . .

# Strength of runway strips

. . .

- 3.4.18 That portion of a strip containing a non-instrument runway within a distance of at least:
- -75 m where the code number is  $\frac{3}{2}$  or  $\frac{4}{7}$ ;
- 55 m where the code number is 3;
- 40 m where the code number is 2; and
- 30 m where the code number is 1;

from the centre line of the runway and its extended centre line should be so prepared or constructed as to minimize hazards arising from differences in load-bearing capacity to aeroplanes which the runway is intended to serve in the event of an aeroplane running off the runway.

• • •

Table 3-1. Taxiway minimum separation distances

	Distance between t and runway cen		Taxiway, other Aircraft Taxiway than stand
	Instrument runways Code number	Non-instrument runways Code number	centre aircraft taxilane Aircraft line stand centre line stand to taxilane, to aircraft taxilane taxiway centre stand centre line
Code letter	1 2 3 4	1 2 3 4	centre line to taxilane to object line object centre line (meters) (metres) (metres)
(1)	(2) (3) (4) (5)	(6) (7) (8) (9)	(10) (11) (12) (13)
A	 77.577.5	37.547.5 – –	23 15.5 19.5 12
В	82 82 152 -	42 52 <del>87</del> 67 –	32 20 28.5 16.5
C	88 88 158 158	48 58 <del>93</del> 73 93	44 26 40.5 22.5
D	166 166	<del>101</del> 101 81	63 37 59.5 33.5
E	172.5172.5	<del>107.5</del> 107.5 87.5	76 43.5 72.5 40
F	180 180	<del>115</del> 115 95	91 51 87.5 47.5

• • •

# Strength of runway end safety areas

3.5.12 A runway end safety area shall be so prepared or constructed as to reduce the risk of damage to an aeroplane undershooting or overrunning the runway, enhance aeroplane deceleration and facilitate the movement of rescue and firefighting vehicles as required in 9.2.34 33 & 9.2.35 34.

Note.— Guidance on the strength of a runway end safety area is given in the Aerodrome Design Manual (Doc 9157), Part 1.

# 3.11 Taxiway strips

• • •

# Grading of taxiway strips

- 3.11.4 *The centre portion of a taxiway strip should provide a graded area to a distance from the centre line of the taxiway of not less than that given by the following tabulation:*
- 10.25 m where the OMGWS is up to but not including 4.5 m;
- 11 m where the OMGWS is 4.5 m up to but not including 6 m;
- 12.50 m where the OMGWS is 6 m up to but not including 9 m;
- $-\frac{18.50}{17}$  m where the OMGWS is 9 m up to but not including 15 m, where the code letter is D;
- 19 m where the OMGWS is 9 m up to but not including 15 m, where the code letter is E;
- 22 m where the OMGWS is 9 m up to but not including 15 m, where the code letter is F.

Note.— Guidance on width of the graded portion of a taxiway is given in the Aerodrome Design Manual (Doc 9157), Part 2.

• • •

# 3.12 Holding bays, runway-holding positions, intermediate holding positions and road-holding positions

• •

Table 3-2. Minimum distance from the runway centre line to a holding bay, runway-holding position or road-holding position

	Code number						
Type of runway	1	2	3	4			
Non-instrument	30 m	40 m	<del>75m</del> 55 m	75 m			
Non-precision approach	40 m	40 m	75 m	75 m			
Precision approach category I	60 m <sup>b</sup>	60 m <sup>b</sup>	90 m <sup>a,b</sup>	$90 \text{ m}^{a,b}$			
Precision approach categories II and III	_	_	90 m <sup>a,b</sup>	90 m <sup>a,b</sup>			
Take-off runway	30 m	40 m	<del>75m</del> 55 m	75 m			

• • •

#### Location

. . .

- 3.12.9 Until 20 November 2030, the location of a runway-holding position established in accordance with 3.12.3 shall be such that a holding aircraft or vehicle will not infringe the obstacle free zone, approach surface, take-off climb surface or ILS/MLS critical/sensitive area or interfere with the operation of radio navigation aids.
- 3.12.9 As of 21 November 2030, the location of a runway-holding position established in accordance with 3.12.3 shall be such that a holding aircraft or vehicle will not infringe the inner approach surface, inner transitional surfaces, balked landing surface, approach surface, take-off climb surface or ILS/MLS critical/sensitive area or interfere with the operation of other radio navigation aids.

### 3.13 Aprons

#### General

- 3.13.1 Aprons shall be provided where necessary to permit the on- and off-loading of passengers, cargo or mail as well as the servicing of aircraft without interfering with the aerodrome traffic.
- 3.13.2 The design of aprons shall take into consideration criteria for safe ground handling, including:
- a) sufficient space between aircraft stands to enable personnel and equipment to move safely and efficiently;
- b) adequate apron markings, apron signs and apron floodlighting;
- c) adequate staging and storage areas for ground support equipment (GSE);
- d) positioning of fixed ground services;
- e) storage areas for unit load devices (ULD);
- f) adequate access and egress routes for fuel, GSE and emergency vehicles;
- g) clearly delineated and visible access and egress routes for passengers;
- h) new technologies (electric charging points, autonomous vehicles, etc.);
- i) avoidance of rear of aircraft stand service roads wherever practicable; and
- *j)* appropriate protection for persons, equipment and infrastructure from jet blast and propeller wash.

Note.— Further guidance on apron design and markings is given in the Aerodrome Design Manual (Doc 9157), Part 4 — Visual Aids, and the Airport Planning Manual (Doc 9184), Part 1— Master Planning.

#### Size of aprons

3.13.<del>2</del>3 When provided the total apron area shall be adequate to permit safe and expeditious handling of the aerodrome traffic at its maximum anticipated density.

#### Strength of aprons

3.13.34 Each part of an apron shall be capable of withstanding the traffic of the aircraft it is intended

to serve, due consideration being given to the fact that some portions of the apron will be subjected to a higher density of traffic and, as a result of slow moving or stationary aircraft, to higher stresses than a runway.

# Slopes on aprons

Code letter

- 3.13.45. Slopes on an apron, including those on an aircraft stand taxilane, shall be sufficient to prevent accumulation of water on the surface of the apron but shall be kept as level as drainage requirements permit.
- 3.13.56 On an aircraft stand the maximum slope shall not exceed 1 per cent.

# Clearance distances on aircraft stands

Clearance

3.13.67 An aircraft stand shall provide the following minimum clearances between an aircraft entering or exiting the stand and any adjacent building, aircraft on another stand and other objects:

0000 10001	010010110
$\boldsymbol{A}$	3 m
B	3 m
C	4.5 m
D	7.5 m
E	7.5 m
$\boldsymbol{F}$	7.5 m

When special circumstances so warrant, these clearances may be reduced at a nose-in aircraft stand, where the code letter is D, E or F:

- a) between the terminal, including any fixed passenger boarding bridge, and the nose of an aircraft; and
- b) over any portion of the stand provided with azimuth guidance by a visual docking guidance system.

. . .

# CHAPTER 4. OBSTACLE RESTRICTION AND REMOVAL

Existing Text of Chapter 4 with some modification of Table 4-1 has been made applicable until 20 November 2030. As of 21 Nov 2030 a complete new text has been inserted in Chapter 4.

(Applicable until 20 November 2030)

Table 4-1. Dimensions and slopes of obstacle limitation surfaces — Approach runways

# APPROACH RUNWAYS

				RI	UNWAY	CLAS	SIFICAT	ION		
									ision ap	
	Non-instrument Code number		Non-precision approach Code number			I Code number		II or III Code number		
Surface and dimensions <sup>a</sup>	1	2	3	4	1,2	3	4	1,2	3,4	3,4
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(9)	(10)	(11)
CONICAL										
Slope	5%	5%	5%	5%	5%	5%	5%	5%	5%	5%
Height	35 m	55 m	75 m	100 m	60 m	75 m	100 m	60 m	100 m	100 m
INNER HORIZONTAL										
Height	45 m	45 m	45 m	45 m	45 m	45 m	45 m	45 m	45 m	45 m
Radius	2 000	2 500	4 000	4 000	3 500	4 000	4 000	3 500	4 000	4 000 m
	m	m	m	m	m	m	m	m	m	
INNER APPROACH										
Width				_	_	_	_		120 m <sup>e</sup>	
Distance from threshold				_	_	_	_	60 m	60 m	60 m
Length	_		_	_	_	_		900 m	900 m	900 m
Slope								2.5%	2%	2%
APPROACH										
Length of inner edge	60 m	80 m	<del>150</del> 110m	150 m	140 m	280 m	280 m	140 m	280 m	280 m
Distance from threshold	30 m	60 m	60 m	60 m	60 m	60 m	60 m	60 m	60 m	60 m
Divergence (each side)	10%	10%	10%	10%	15%	15%	15%	15%	15%	15%
First section										
Length	1 600 m	2 500 m	3 000 m	3 000 m	2 500 m	3 000 m	3 000 m	3 000 m	3 000 m	3 000 m

								Prec	ision ap	
		Non-instrument Code number			8	Non-precision approach Code number			I number	II or III Code number
Surface and dimensions <sup>a</sup>	1	2	3	4	1,2	3	4	1,2	3,4	3,4
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(9)	(10)	(11)
Slope	5%	4%	3.33%	2.5%	3.33%	2%	2%	2.5%	2%	2%
Second section										
Length		_	—	_	—	3 600 m <sup>b</sup>	3 600 m <sup>b</sup>	12 000 m	3 600 m <sup>b</sup>	3 600 m <sup>b</sup>
Slope	_	_		_	_	2.5%	2.5%	3%	2.5%	2.5%
Horizontal section										
Length	_	_	_	_		8 400 m <sup>b</sup>	8 400 m <sup>b</sup>		8 400 m <sup>b</sup>	$8~400~\text{m}^\text{b}$
Total length	—	—	_	_	_	15 000 m	15 000 m	15 000 m	15 000 m	15 000 m
TRANSITIONAL Slope	20%	20%	14.3%	14.3%	20%		14.3%	14.3%		14.3%
INNER TRANSITIONAL Slope	_	_	_		_	_	_	40%	33.3%	33.3%
BALKED LANDING SURFACE										
Length of inner edge		_	_	_		_		90 m	120 me	$120 \text{ m}^{\text{e}}$
Distance from threshold	_	_	_	_	_	_	_	c	1 800 m <sup>d</sup>	1 800 m <sup>d</sup>
Divergence (each side) Slope	_	_	_	_	_	_	_	10% 4%	10% 3.33%	10% 3.33%

...

#### New text inserted as follows:

# CHAPTER 4. OBSTACLE RESTRICTION AND REMOVAL

(Applicable as of 21 November 2030)

Note 1.— This chapter describes the management of obstacles within the aerodrome boundary and in its vicinity. The following specifications allow Aerodrome Operator to define the airspace around aerodromes to be maintained free from obstacles and the airspace where flexibility can be applied in managing the obstacle environment. This permits the existing and intended aeroplane operations at the aerodromes to be conducted safely and prevent the aerodromes from becoming restricted and eventually unusable by the growth of obstacles.

This is achieved by establishing obstacle limitation surfaces (OLS) consisting of obstacle free surfaces (OFS) and obstacle evaluation surfaces (OES).

- Note 2.— The lateral and vertical extent of the OLS are being used in defining the requirements for the collection of terrain and obstacle data sets. Provisions on terrain and obstacle data sets are contained in Annex 15 Aeronautical Information Services, Chapter 5.
- Note 3.— The establishment of, and requirements for, an obstacle protection surface for visual approach slope indicator systems are specified in Chapter 5, 5.3.5.41 to 5.3.5.45 of ANO 14 VOL-I.

#### 4.1 General

- 4.1.1 Aerodrome Operator shall establish a process to prevent the growth of obstacles, both fixed and mobile, that may affect the safety or regularity of flight operations at an aerodrome.
  - Note 1.— Specifications concerning the process to be established by the State are contained in PANS-Aerodromes (Doc 9981), Part II, Chapter 10.
  - Note 2.— Taxiing aircraft, aircraft on tow and traversing vehicles are considered mobile objects whereas buildings, parked aircraft and vehicles are considered fixed objects.

#### 4.2 Obstacle free surfaces (OFS)

*Note.*— The purpose of the obstacle free surfaces is to establish airspace that preserves the accessibility of the aerodrome and the safety of operations by protecting aeroplanes during approaches and go-arounds.

# 4.2.1 Approach surface

- Note1.— The purpose of the approach surface is to establish the airspace to be maintained free from obstacles to protect an aeroplane in the visual phase of the approach-to-land manoeuvres following a standard 3.0° approach. See Figure 4-1.
  - 4.2.1.1 *Description*. An inclined surface preceding the threshold.
  - 4.2.1.2 *Characteristics*. The limits of the approach surface shall comprise:
  - a) an inner edge of specified length, horizontal and perpendicular to the extended centre line of the runway and located at a specified distance before the threshold;
  - b) two sides originating at the ends of the inner edge and diverging uniformly at a specified rate from the extended centre line of the runway; and
  - c) an outer edge parallel to the inner edge.
- 4.2.1.3 The surface mentioned in 4.2.1.2 shall be varied when lateral offset, angular offset or curved approaches are utilized; two sides originating at the ends of the inner edge and diverging uniformly at a specified rate from the extended centre line of the lateral offset, angular offset or curved ground track.
  - 4.2.1.4 The elevation of the inner edge shall be equal to the elevation of the midpoint of the threshold.
  - 4.2.1.5 The slope of the approach surface shall be measured:
  - a) when straight-in approaches are utilized in the vertical plane containing the centre line of the runway and its extension; and
  - b) when lateral offset, angular offset or curved approaches are utilized along any straight part of the approach, in the vertical plane containing the centre line of the lateral offset, angular offset or curved ground track or, along any curved part of the approach, in the vertical plane tangent with the curved ground track.
- 4.2.1.6 Except where the approach surface is raised to comply with approach angles greater than 3.0°, the slope of the approach surface shall not be greater than, and their other dimensions not less than, those specified in Table 4-1 for non-instrument runways and Table 4-2 for instrument runways.

- 4.2.1.7 The slope of the approach surface shall as far as practicable not be increased to facilitate the growth of obstacles.
- Note.— The slope of the approach surface is intended to adapt to approach operations that have a slope higher than 3.0°. Specifications concerning the modification of the approach surface are contained in PANS-Aerodromes (Doc 9981), Part II, Chapter 10.
- 4.2.1.8 Where the approach angle is lower than 3.0°, the slope of the approach surface shall be decreased.
- 4.2.1.9 Where the slope of the obstacle protection surface of a visual approach slope indicator system is lower than that indicated in Table 4-1 and Table 4-2, the slope of the approach surface shall be decreased to match that of the obstacle protection surface.
  - Note.—See Chapter 5, 5.3.5 on the obstacle protection surface.
- 4.2.1.10 Where the slope of the approach surface is reduced, corresponding adjustment in the length of the approach surface shall be made to provide protection to a height equal to that reached with the slopes and lengths in Table 4-1 and Table 4-2.
- 4.2.1.11 On instrument approach runways, where the obstacle clearance height is higher than 150 m (500 ft) above the threshold, the length of the approach surface shall not be less than:
  - a) the value indicated in Table 4-2; or
  - b) that necessary to reach the obstacle clearance height;

whichever is greater.

Table 4-1. Dimensions and slopes of approach surface — Non-instrument runways

Aeroplane design group	I	IIA-IIB	ΙΙС	III	IV	V
Distance from threshold	30 m	60 m	60 m	60 m	60 m	60 m
Length of inner edge	$60 \text{ m}^{a \text{ b}}$	$80  m^{c  d}$	$100  \text{m}^{\text{d}}$	125 m	135 m	150 m
Divergence	10 %	10 %	10 %	10 %	10 %	10 %
Length	1 600 m <sup>e</sup>	$2500\ m^e$	$2\;500\;\;m^e$	$2\ 500\ m^e$	$2\;500\;\;m^e$	2 500 m <sup>e</sup>
Slope	5 % <sup>f</sup>	4 % <sup>f</sup>	3.33 % <sup>f</sup>	$3.33 \%^{f}$	3.33 % <sup>f</sup>	$3.33 \%^{\rm f}$

<sup>&</sup>lt;sup>a</sup> Where runway width is above 23 m and up to 30 m, the length of inner edge is increased to 80 m.

<sup>&</sup>lt;sup>b</sup> Where runway width is above 30 m, the length of inner edge is increased to 100 m.

<sup>&</sup>lt;sup>c</sup> Where runway width is above 30 m and up to 45 m, the length of inner edge is increased to 100 m.

<sup>&</sup>lt;sup>d</sup> Where runway width is above 45 m, the length of inner edge is increased to 110 m.

<sup>&</sup>lt;sup>e</sup> See 4.2.1.10.

<sup>&</sup>lt;sup>f</sup> See 4.2.1.8 and 4.2.1.9.

Table 4-2. Dimensions and slopes of approach surface — Instrument runways

Aeroplane design group	I	IIA-IIB	IIC	Ш	IV	V
Distance from threshold	60 m	60 m	60 m	60 m	60 m	60 m
Length of inner edge	$110 \text{ m}^{\text{ a}}$	$125 \text{ m}^{\text{b}}$	$155 \text{ m}^{c}$	175 m	185 m	200 m
Divergence	10%	10%	10%	10 %	10%	10%
Length	$4\ 500\ m^d$	$4\ 500\ m^d$	$4\ 500\ m^{\text{d}}$	$4\ 500\ m^{\text{d}}$	$4\ 500\ m^{\text{d}}$	$4\ 500\ m^d$
Slope	3.33% <sup>e</sup>	3.33% <sup>e</sup>	3.33% <sup>e</sup>	3.33% <sup>e</sup>	3.33% <sup>e</sup>	3.33% <sup>e</sup>

<sup>&</sup>lt;sup>a</sup> When the runway width is above 30 m, the length of inner edge is increased to 125 m.

# **4.2.2** Transitional surfaces

Note.— The purpose of the transitional surfaces is to establish the airspace to be maintained free from fixed obstacles to protect an aeroplane in the overflight of the runway or go-around manoeuvre following a standard  $3.0^{\circ}$  approach, beyond the approach surface. See Figure 4-1.

- 4.2.2.1 *Description. Transitional surfaces.* A complex surface along and at a specified distance from the runway centre line and part of the side of the approach surface that slopes upwards and outwards to a specified height.
  - 4.2.2.2 *Characteristics.* The limits of a transitional surface shall comprise:
  - a) a lower edge beginning on the side of the approach surface at the elevation of the upper edge and extending down the side of the approach surface to the inner edge of the approach surface and from there along a line extending parallel to and at a specified distance from the runway centre line and its extension, to the end of the strip; and
  - b) an upper edge located at 60 m above the elevation of the highest threshold of the runway.
  - 4.2.2.3 The elevation of a point on the lower edge shall be:
  - a) along the side of the approach surface equal to the elevation of the approach surface at that point; and
  - b) along the runway centre line and its extension after the threshold equal to the elevation of the nearest point on the centre line of the runway or its extension.

Note.— As a result of b) the transitional surfaces along the line parallel to the runway centre line will be curved if the runway profile is curved, or a plane if the runway profile is a straight line. The upper edge of the transitional surfaces will also be a curved or a straight line depending on the runway profile.

- 4.2.2.4 The slope of the transitional surfaces shall be measured in a vertical plane perpendicular to the vertical plane containing the runway centre line or its extension.
  - 4.2.2.5 The slope of the transitional surface shall not be greater than 20 per cent.

<sup>&</sup>lt;sup>b</sup> When the runway width is above 30 m, the length of inner edge is increased to 140 m.

<sup>&</sup>lt;sup>c</sup> When the runway width is 30 m or less, the length of inner edge is decreased to 140 m.

<sup>&</sup>lt;sup>d</sup> See 4.2.1.10 and 4.2.1.11.

<sup>&</sup>lt;sup>e</sup> See 4.2.1.8 and 4.2.1.9.




Figure 4-1. Approach surface and transitional surfaces

# 4.2.3 Inner approach surface

- Note.— The inner approach surface protects an aeroplane against fixed and mobile obstacles before the threshold, in the descent phase of the balked landing or late go-around manoeuvres following a standard 3.0° approach. See Figure 4-2 and Figure 4-3.
- 4.2.3.1 *Description. Inner approach surface*. A rectangular portion of the approach surface immediately preceding the threshold.
  - 4.2.3.2 *Characteristics.* The limits of the inner approach surface shall comprise:
  - a) an inner edge coincident with the location of the inner edge of the approach surface but of its own specified length;
  - b) two sides originating at the ends of the inner edge and extending parallel to the vertical plane containing the centre line of the runway; and
  - c) an outer edge parallel to the inner edge.
- 4.2.3.3 The surface mentioned in 4.2.3.2 shall be varied when lateral offset, angular offset or curved approaches are utilized; two sides originating at the ends of the inner edge and extending parallel to the extended centre line of the lateral offset, angular offset or curved ground track.
- 4.2.3.4 The dimensions of the inner approach surface for non-instrument runway shall not be less than those specified in Table 4-3.
- 4.2.3.5 The dimensions of the inner approach surface for non-precision approach runway shall not be less than those specified in Table 4-4.
- 4.2.3.6 The dimensions of the inner approach surface for precision approach runway shall not be less than those specified in Table 4-5.
- 4.2.3.7 If the slope of the approach surface is reduced, the length of the inner approach surface shall be increased to provide protection to a height of 45 m (150 ft).

Table 4-3. Dimensions of inner approach surface — Non-instrument runways

Aeroplane design group	I	IIA-IIB	ПС	III	IV	V
Length of inner edge	60 m	80 m	100 m	110 m	120 m	120 m <sup>a</sup>
Length	$900 \text{ m}^{\text{b}}$	1 125 m <sup>b</sup>	1 350 m <sup>b</sup>			

<sup>&</sup>lt;sup>a</sup> The length of inner edge is increased to 140 m on those aerodromes that accommodate a code letter F aeroplane that is not equipped with digital avionics that provide steering commands to maintain an established track during the go-around manoeuvre.

<sup>b</sup> See 4.2.3.7.

Table 4-4. Dimensions of inner approach surface — Non-precision approach runways

Aeroplane design group	I	IIA-IIB	ис	Ш	IV	V
Length of inner edge	80 m	80 m	120 m	120 m	120 m	120 m <sup>a</sup>
Length	1 350 m <sup>b</sup>					

<sup>&</sup>lt;sup>a</sup> The length of inner edge is increased to 140 m on those aerodromes that accommodate a code letter F aeroplane that is not equipped with digital avionics that provide steering commands to maintain an established track during the go-around manoeuvre.

Table 4-5. Dimensions of inner approach surface — Precision approach runways

Aeroplane design group	I	IIA-IIB	IIC	III	IV	V
Length of inner edge	90 m	90 m	120 m	120 m	120 m	$120 \text{ m}^{\text{a}}$
Length	$1~350~\text{m}^\text{b}$	$1\ 350\ m^b$	$1\;350\;m^b$	$1~350~\text{m}^\text{b}$	$1~350~\text{m}^\text{b}$	$1~350~m^b$

<sup>&</sup>lt;sup>a</sup> The length of inner edge is increased to 140 m on those aerodromes that accommodate a code letter F aeroplane that is not equipped with digital avionics that provide steering commands to maintain an established track during the go-around manoeuvre.

#### 4.2.4 Inner transitional surfaces

Note.— The inner transitional surfaces aim at establishing the airspace to be maintained free from fixed and mobile obstacles to protect an aeroplane in the climb phase of the balked landing or late go-around manoeuvres following a standard 3.0° approach, beyond the inner approach surface. See Figure 4-2 and Figure 4-3.

#### 4.2.4.1 Description.—Inner transitional surfaces:

- a) Non-instrument and non-precision approach runways A complex surface at a specified distance
  from the runway centre line consisting of two successive sections: a first section that rises vertically
  to a given height, followed by a second inclined section that slopes upwards and outwards to a
  specified height; and
- b) *Precision approach runways* A surface similar to the transitional surface but closer to the runway.

#### 4.2.4.2 *Characteristics.*—On non-instrument and non-precision approach runways:

- a) the limits of the vertical section of the inner transitional surface shall comprise:
  - a lower edge beginning on the side of the inner approach surface at a specified height above the inner edge of that surface, extending down the side of the inner approach surface to its inner edge, from there along a line parallel to and at a specified distance from the runway centre line, and its extension, to a specified length after the threshold and from there, vertically to a specific height; and
  - 2) an upper edge parallel to, and at a specified height above, the runway centre line;

<sup>&</sup>lt;sup>b</sup> See 4.2.3.7.

<sup>&</sup>lt;sup>b</sup> See 4.2.3.7.

- b) the limits of the inclined section of the inner transitional surface shall comprise:
  - 1) a lower edge beginning at the end of the inner approach surface and extending down the side of the inner approach surface to the upper edge of the vertical section, from there along the upper edge of the vertical section; and
  - 2) an upper edge parallel to and at 60 m above the elevation of the highest threshold of the runway.
- 4.2.4.3 *Characteristics.* On precision approach runways, the limits of the inner transitional surface shall comprise:
  - a) a lower edge beginning at the end of the inner approach surface and extending down the side of the inner approach surface to the inner edge of that surface, from there along a line parallel to and at a specified distance from the runway centre line and its extension to the inner edge of the balked landing surface and from there up the side of the balked landing surface to the upper edge; and
  - b) an upper edge located at 60 m above the elevation of the highest threshold of the runway.
  - 4.2.4.4 On non-instrument and non-precision approach runways, the elevation of a point shall be:
  - a) on the lower edge of the vertical section:
    - 1) along the side of the inner approach surface equal to the elevation of the inner approach surface at that point; and
    - 2) after the inner edge of the inner approach surface equal to the elevation of the nearest point on the centre line of the runway or its extension;
  - b) on the upper edge of the vertical section equal to a specific height above the nearest point on the centre line of the runway or its extension;
  - c) on the lower edge of the inclined section:
    - 1) along the side of the inner approach surface equal to the elevation of the inner approach surface at that point; and
    - 2) along the upper edge of the lower section equal to the elevation of the upper edge of the lower section at that point.

Note.— As a result of a), b) and c) the two sections of the inner transitional surfaces along the centre line of the runway will be curved if the runway profile is curved, or a plane if the runway profile is a straight line. The upper edges of both sections of the inner transitional surfaces will also be curved or straight lines depending on the runway profile.

- 4.2.4.5 On precision approach runways, the elevation of a point on the lower edge shall be:
- a) along the side of the inner approach surface and balked landing surface equal to the elevation of the particular surface at that point; and
- b) along the runway centre line and its extension equal to the elevation of the nearest point on the centre line of the runway or its extension;

Note.— As a result of b) the inner transitional surfaces along the centre line of the runway will be curved if the runway profile is curved, or a plane if the runway profile is a straight line. The upper edge of the inner transitional surfaces will also be a curved or a straight line depending on the runway profile.

- 4.2.4.6 The slope of the inner transitional surfaces shall be measured:
- a) between the inner edges of the inner approach surface and balked landing surface: in a vertical plane perpendicular to the vertical plane containing the runway centre line and its extension;
- b) before the inner edge of the inner approach surface:
  - 1) where straight-in approaches are utilized: in a vertical plane perpendicular to the vertical plane containing the runway centre line and its extension; and
  - 2) where lateral offset, angular offset or curved approaches are utilized: along any straight part of the approach, in a vertical plane perpendicular to the vertical plane containing the straight part of the approach or, along any curved part of the approach, in the vertical plane tangent with the curved ground track.
- 4.2.4.7 The slope of the inner transitional surfaces for non-instrument runway shall not be greater than, and the height of the vertical section not lower than, that specified in Table 4-6.
- 4.2.4.8 The slope of the inner transitional surfaces for non-precision approach runway shall not be greater than, and the height of the vertical section not lower than, that specified in Table 4-7.
- 4.2.4.9 The slope of the inner transitional surfaces for precision runway shall not be greater than that specified in Table 4-8.

Table 4-6. Dimensions of inner transitional surfaces — Non-instrument runways

Aeroplane design group	I	IIA-IIB	IIC	III	IV	V
Height of the vertical section	6 m	6 m	8.4 m	10 m	5 m	5 m
Slope of the inclined section	40 %	40 %	33.3%	33.3%	33.3%	33.3%
Length	a	a	1 800 m <sup>b</sup>			

<sup>&</sup>lt;sup>a</sup> To the end of the strip.

Table 4-7. Dimensions of inner transitional surfaces — Non-precision approach runways

Aeroplane design group	I	IIA-IIB	IIC	III	IV	V
Height of the vertical section	6 m	6 m	5 m	5 m	5 m	5 m
Slope of the inclined section	40 %	40 %	33.3%	33.3%	33.3%	33.3%
Length	a	a	1 800 m <sup>b</sup>			

<sup>&</sup>lt;sup>a</sup> To the end of the strip.

<sup>&</sup>lt;sup>b</sup> Or to the end of the runway, whichever is less.

<sup>&</sup>lt;sup>b</sup> Or to the end of the runway, whichever is less.

Table 4-8. Slopes of inner transitional surfaces — Precision approach runways

Aeroplane design group	I	IIA-IIB	IIC	III	IV	V
Slope	40 %	40 %	33.3%	33.3%	33.3%	33.3%
Length	a	a	a	a	a	a
<sup>a</sup> See 4.2.4.3.						

# 4.2.5 Balked landing surface

Note.— The balked landing surface is intended to be implemented on precision approach runways, where the balked landing might be initiated at low height above the threshold and the climb phase of the manoeuvre is not necessarily covered by the inner transitional surfaces. The balked landing surface aims at establishing the airspace to be maintained free from fixed and mobile obstacles to protect an aeroplane in the climb phase of the balked landing or late go-around manoeuvres following a standard 3.0° approach, beyond the inner transitional surfaces. See Figure 4-3.

- 4.2.5.1 *Description. Balked landing surface*. An inclined surface located at a specified distance after the threshold, extending between the inner transitional surfaces.
  - 4.2.5.2 *Characteristics.* The limits of the balked landing surface shall comprise:
  - a) an inner edge horizontal and perpendicular to the centre line of the runway and located at a specified distance after the threshold;
  - b) two sides originating at the ends of the inner edge and diverging uniformly at a specified rate from the vertical plane containing the centre line of the runway; and
  - c) an outer edge parallel to the inner edge and located at 60 m above the elevation of the highest threshold of the runway.
- 4.2.5.3 The elevation of the inner edge shall be equal to the elevation of the nearest point on the runway centre line.
- 4.2.5.4 The slope of the balked landing surface shall be measured in the vertical plane containing the centre line of the runway and its extension;
- 4.2.5.5 The slope of the balked landing surface shall not be greater than, and its other dimensions not less than, those specified in Table 4-9.

Table 4-9. Dimensions and slopes of balked landing surface

Aeroplane design group	I	IIA-IIB	IIC	III	IV	V
Distance from threshold	a	a	1 800 m <sup>b</sup>			
Length of inner edge	90 m	90 m	120 m	120 m	120 m	120 m <sup>c</sup>
Divergence (each side)	10%	10%	10%	10%	10%	10%
Slope	5%	4%	3.33%	3.33%	3.33%	3.33%

a. End of the strip.

b. Or end of runway whichever is less.

c. The length of inner edge is increased to 140 m on those aerodromes that accommodate a code letter F aeroplane that is not equipped with digital avionics that provide steering commands to maintain an established track during the go-around manoeuvre.




Figure 4-2 Inner approach and inner transitional surfaces on a non-precision approach runway




Figure 4-3 Obstacle free zone on a precision approach runway

# 4.3 Obstacle evaluation surfaces (OES)

- Note 1.— The purpose of the obstacle evaluation surfaces is to establish the airspace necessary to determine the acceptability of obstacles by evaluating their impact on existing and/or intended aeroplane operations at an aerodrome. The impact is evaluated on safety, regularity and demand of the operations identified by Authority
- Note 2.— The OES detailed in the following specifications address most common flight operations and operating minima. When the flight operations differ (e.g. variance in alignment, approach slope, approach minima) specific obstacle evaluation surfaces may need to be established. Depending on the flight operations and procedures available at an aerodrome, the OES may have specifications as specified in the following provisions or may be varied to fit the operations at the aerodrome (e.g. in case of increased minima or where circling does not occur on one side of the runway). There will be instances where additional obstacle evaluation surfaces, beyond what are specified in this section, may be required as the OES or its variations do not satisfactorily cover the local aeroplane operations specific to the aerodrome.
- Note 3.— Detailed specifications on the variation of the OES and their design are contained in PANS-Aerodromes (Doc 9981).

#### 4.3.1 General

- 4.3.1.1 The Aerodrome Operator shall ensure that the obstacle evaluation surfaces specified in 4.5.2 have been established to protect the existing and/or intended aeroplane operations at an aerodrome.
- 4.3.1.2 The characteristics and dimensions of the obstacle evaluation surfaces shall be in accordance with the provisions contained in 4.3.2 to 4.3.6.
- 4.3.1.3 Where it is necessary to preserve the accessibility of an aerodrome to existing and planned operations, the provisions applicable to OFS contained in 4.4.4 to 4.4.8 shall apply to the identified obstacle evaluation surface.
  - Note.— Detailed specifications are contained in PANS-Aerodromes (Doc 9981), Part II, Chapter 10.

#### 4.3.2 Horizontal surface

- Note.— The purpose of the horizontal surface is to protect the airspace for circling procedures. The horizontal surface also provides some protection for visual circuits and terminal instrument flight procedures, including PBN approaches, early turning missed approaches and early turning departures. The design of the horizontal surface is consistent with the dimensions of the visual manoeuvring area provided in PANS-OPS, (Doc 8168, Volume II, Part 1, Section 4, Chapter 7).
- 4.3.2.1 *Description. Horizontal surface*. A surface, or a combination of surfaces, located in a horizontal plane, or in a series of horizontal planes, above an aerodrome and its environs.
- 4.3.2.2 *Characteristics.* The outer limits of the horizontal surface should be circular arcs centred on runway thresholds joined tangentially by straight lines.
  - 4.3.2.3 The height of the horizontal surface shall be measured above the aerodrome elevation.
- 4.3.2.4 A horizontal surface should have a radius of not less than, and a height of not greater than, those specified in Table 4-10.

Table 4-10. Dimensions of horizontal surface

Aeroplane design group	I-IIA	IIB	IIC	III	IV	V
Radius	3 350 m	5 350 m	10 750 m	10 750 m	10 750 m	10 750 m
Height	45 m	60 m	90 m	90 m	90 m	90 m

Note.— Where a runway is intended for the operations of aeroplanes of different aeroplane design groups, all the horizontal surfaces specified by the radii and heights associated with these groups are retained and the horizontal surface is composed of multiple surfaces located at different heights above the aerodrome elevation.




Figure 4-4. Horizontal surface

# 4.3.3 Surface for straight-in instrument approaches

- Note.— The purpose of the surface for straight-in instrument approaches is to establish the airspace where obstacles may have an impact on straight-in instrument approaches, where the horizontal surface(s) or parts thereof are not established. As a single obstacle evaluation surface cannot address the variety of all possible instrument approach procedures, only most common straight-in instrument approaches other than precision approaches are considered. The surfaces for precision approaches are established in 4.3.4.
- 4.3.3.1 *Description. Surface for straight-in instrument approaches.* A combination of surfaces, located in a series of horizontal planes above an aerodrome and its environs.
  - 4.3.3.2 *Characteristics.* The surface for straight-in instrument approaches should consist of:
  - a) a lower part corresponding to the horizontal surface applicable to ADG I;
  - b) an upper part corresponding to that part of the horizontal surface applicable to ADG II and III extending beyond the lateral limit of the lower section and delineated by the rectangle of following sides:
    - 1) two shorter sides perpendicular to and centred on the runway centre line and its extension; and
    - 2) two longer sides extending parallel to the runway centre line and its extension from a given distance before and after the thresholds of the runway.
- Note.— The characteristics of the surface for straight-in instrument approaches specified in 4.3.3.2 are applicable to all ADGs.
- 4.3.3.3 The heights of the lower section and upper section shall be measured above the aerodrome elevation.
- 4.3.3.4 The heights of the surface for straight-in instrument approaches should not be greater than, and its other dimensions not less than, those specified in Table4-11.

Table 4-11. Dimensions of surface for straight-in instrument approaches

	Aeroplane design group	I to V
Lower section		45 m
	Height	
		Horizontal
	Length	OES as
		per ADG I
_	Height	60 m
Upper section _	Length of shorter side	7 410 m
	Length of longer side from	5 350 m
	the threshold or thresholds	




Figure 4-5. Surface for straight-in instrument approaches

# 4.3.4 Surface for precision approaches

Note.— The purpose of the surface for precision approaches is to establish the airspace where obstacles may have an impact on common straight-in precision approach procedures (using ILS or MLS, ground-based augmentation system (GBAS) or satellite-based augmentation system (SBAS) CAT I). The design of the surface is consistent with the dimensions of the basic ILS surfaces provided in PANS-OPS (Doc 8186) Volume II, Part II, Section I, Chapter 1. Adjustments to the surface may be necessary in case of offset procedures.

- 4.3.4.1 *Description. Surface for precision approaches*. A complex surface composed of:
- a) an approach component consisting of an inclined surface preceding the threshold;

- b) a missed approach component consisting of an inclined surface located at a specific distance after the threshold;
- c) transitional components consisting of complex surfaces at a specified distance from the runway centre line and along the approach component and missed approach component, that slopes upwards and outwards; and
- d) a lower component specified by a rectangular surface within the inner edges of the above components.
- Note.— The transitional components consist of a pair of surfaces, located on either side of the runway centre line. Each surface of this pair is called a transitional component.
- 4.3.4.2 *Characteristics.* The limits of the approach component of the surface for precision approaches should comprise:
  - a) an inner edge of specified length, horizontal and perpendicular to the extended centre line of the runway and located at a specified distance before the threshold;
  - b) two sides originating at the ends of the inner edge and diverging uniformly at a specified rate from the extended centre line of the runway to a specified distance and diverging uniformly thereafter at another specified rate for the remainder of the length of the approach component; and
  - c) an outer edge parallel to the inner edge.
- 4.3.4.3 The elevation of the inner edge of the approach component shall be equal to the elevation of the midpoint of the threshold.
- 4.3.4.4 The slope of the approach component shall be measured in the vertical plane containing the centre line of the runway and its extension.
- 4.3.4.5 *Characteristics.* The limits of the missed approach component of surface for precision approaches should comprise:
  - a) an inner edge of specified length, horizontal and perpendicular to the extended centre line of the runway and located at a specified distance after the threshold;
  - b) two sides originating at the ends of the inner edge and diverging uniformly at a specified rate from the extended centre line of the runway to a specified distance and diverging uniformly thereafter at another specified rate for the remainder of the length of the missed approach component; and
  - c) an outer edge parallel to the inner edge.
- 4.3.4.6 The elevation of the inner edge of the missed approach component shall be equal to the elevation of the midpoint of the threshold.
- Note.— In some cases, the inner edge of the missed approach component may be below the elevation of the midpoint of the threshold, for example where runways slope upward.
- 4.3.4.7 The slope of the missed approach component shall be measured in the vertical plane containing the centre line of the runway and its extension.

- 4.3.4.8 *Characteristics.* The limits of the transitional component of the surface for precision approaches should comprise:
  - a) a lower edge beginning on the side of the approach component at the elevation of the upper edge and extending down the side of the approach component to the inner edge of the approach component, from there along a line extending horizontally to the inner edge of the missed approach component, and from there extending up the side of the missed approach component to the upper edge; and
  - b) an upper edge located at 300 m above the threshold elevation.
  - 4.3.4.9 The elevation of a point on the lower edge of the transitional component shall be:
  - a) along the side of the approach component and missed approach component equal to the elevation of the particular surface at that point; and
  - b) between the inner edges of the approach component and missed approach component equal to the elevation of the midpoint of the threshold.

Note.— In some cases, the lower edge of the transitional component may be below the elevation of the midpoint of the threshold, for example where runways slope upward.

- 4.3.4.10 The slope of the transitional component shall be measured in the vertical plane perpendicular to the centre line of the runway and its extension.
- 4.3.4.11 *Characteristics.* The limits of the lower component of the surface for precision approaches should comprise:
  - a) two shorter sides corresponding with the inner edge of the approach component and missed approach component; and
  - b) two longer sides corresponding with the inner edges of the transitional components.
- 4.3.4.12 The elevation of a point on the lower component shall be equal to the elevation of the midpoint of the threshold.
- 4.3.4.13 The slopes of the different components of the surface for precision approach runways should not be greater than, and their other dimensions not less than, those specified in Table 4-12.

Table 4-12. Dimensions of surface for precision approaches

Aer	oplane design	group	I to V
		Distance from threshold	60 m
		Length of inner edge	300 m
		Length	3 000 m
	$1^{st}$ section	Divergence (each side)	15 %
Approacn component		Slope	2 %
		Length	9 600 m
	$2^{nd}$ section	Divergence (each side)	15 %
		Slope	2.5 %
Missed approach component		Distance after threshold	900 m
		Length of inner edge	300 m

Aeı	Aeroplane design group		
	Length		1 800 m
	1st section	Divergence (each side)	17.48 %
		Slope	2.5 %
		Length	10 200 m
	$2^{nd}$ section	Divergence (each side)	25 %
		Slope	2.5 %
Transitional component		Slope	14.3 %




Figure 4-6. Surface for precision approaches

# 4.3.5 Instrument departure surface

- Note.— The purpose of the instrument departure surface is to establish the airspace where obstacles may have an impact on aircraft following an omnidirectional instrument departure procedure. The design of the instrument departure surface is consistent with the dimensions provided in PANS-OPS (Doc 8168, Volume II, Part I, Section 3, Chapter 4).
- 4.3.5.1 *Description. Instrument departure surface*. An inclined surface, along the runway centre line and its extension after the end of the take-off distance available.
  - 4.3.5.2 *Characteristics.* The limits of the instrument departure surface should comprise:
  - a) an inner edge of specified length, horizontal and perpendicular to the centre line of the runway and located at the end of the take-off distance available;
  - b) two sides originating at the ends of the inner edge and diverging uniformly at a specified rate from the extended centre line of the runway to a specified distance and diverging uniformly thereafter at another specified rate for the remainder of the length of the instrument departure surface; and
  - c) an outer edge parallel to the inner edge.
- 4.3.5.3 The elevation of the inner edge shall be 5 m above the elevation of the runway centre line and its extension at the end of the take-off distance available.
- 4.3.5.4 The slope of the instrument departure surface shall be measured in the vertical plane containing the centre line of the runway and its extension.
- 4.3.5.5 The slope of the instrument departure surface should not be greater than, and its other dimensions not less than, those specified in Table4-13.

Table 4-13. Dimensions of instrument departure surface

Aeroplane design group	I to V
Length of inner edge	300 m
Slope	2.5 %
Length	3 500 m
Divergence	26.8 %
Length	8 300 m
Divergence	57.8 %
	Length of inner edge Slope Length Divergence Length




Figure 4-7. Instrument departure surface

#### 4.3.6 Take-off climb surface

Note 1.— The purpose of the take-off climb surface is to establish the airspace where obstacles may have an impact on aircraft operating limitations during take-off under non-critical operating conditions. The design of the take-off climb surface is consistent with the take-off obstacle clearance limitations provided in the Aeroplane Performance Manual (Doc 10064, Chapter 3), and Annex 6, Part I.

Note 2.— Obstacles that have no impact on aircraft operating limitations during take-off undernon-critical operating conditions could have an impact in case of engine failure or abnormal (e.g. extreme weather conditions) and emergency situations (e.g. system failure).

- 4.3.6.1 *Description. Take-off climb surface*. An inclined surface beyond the end of the take-off distance available.
  - 4.3.6.2 *Characteristics.* The limits of the take-off climb surface should comprise:
  - a) an inner edge horizontal and perpendicular to the centre line of the runway and located at a specified distance beyond the end of the runway or at the end of the take-off distance available;
  - b) two sides originating at the ends of the inner edge, diverging uniformly at a specified rate from the take-off ground track to a specified final width and continuing thereafter at that width for the remainder of the length of the take-off climb surface; and
  - c) an outer edge horizontal and perpendicular to the specified take-off track.
- 4.3.6.3 The above surface should vary when take-off flight paths involving turns are utilized; two sides originating at the end of the inner edge and diverging uniformly at a specified rate from the extended centre line of the take-off ground track to a specified final width, and extending thereafter parallel to the take-off ground track for the remainder of the length of the take-off climb surface.
- 4.3.6.4 The elevation of the inner edge shall be equal to the highest point on the extended runway centre line between the end of the take-off run available and the inner edge of the take-off climb surface.
  - 4.3.6.5 The slope of the take-off climb surface shall be measured:
  - a) in the vertical plane containing the centre line of the runway and its extension where straight takeoff flight path are utilized;
  - b) along any straight part of the take-off flight path, in the vertical plane containing the centre line of the take-off flight path or, along any curved part of the take-off flight path, in the vertical plane tangent with the take-off flight path where take-off flight paths involving turns are utilized.
- 4.3.6.6 On runways intended for operations of aeroplanes with a maximum certificated take-off mass up to 5 700 kg, the slope of the take-off climb surface should not be greater than, and its other dimensions not less than, those specified in Table4-14, except that:
  - a) a lesser length should be adopted for the take-off climb surface where such lesser length would be consistent with procedural measures adopted to govern the outward flight of aeroplanes; and
  - b) a higher slope should be adopted for the take-off climb surface where such slope would be consistent with the operational characteristics of the critical aeroplane operating out of the runway and the local conditions.
- 4.3.6.7 On runways intended for operations of aeroplanes with a maximum certificated take-off mass greater than 5 700 kg, the slope of the take-off climb surface should not be greater than, and its other dimensions not less than, those specified in Table 4-15, except that:
  - a) a lesser length should be adopted for the take-off climb surface where such lesser length would be consistent with procedural measures adopted to govern the outward flight of aeroplanes; and
  - b) higher slope should be adopted for the take-off climb surface where such slope would be consistent with the operational characteristics of the critical aeroplane operating out of the runway and the local conditions.
- 4.3.6.8 The slope of the take-off climb surface shall not be increased to facilitate the growth of obstacles.

Note.— The slope of the take-off climb surface is intended to adapt to the operations of aeroplanes whose climb performances on take-off climb are such that a slope of 2 per cent is not necessary. However, this slope is not intended to be increased to enable the growth of obstacles. Specifications concerning the increase of the slope of the take-off climb surface are contained in PANS-Aerodromes (Doc 9981), Part II, Chapter 10.

4.3.6.9 The operational characteristics of aeroplanes for which the runway is intended should be examined to see if it is desirable to reduce the slope specified in Table 4-14 and Table 4-15 to 1.6 per cent when critical operating conditions are to be catered to. If the specified slope is reduced, corresponding adjustment in the length of the take-off climb surface should be made so as to provide protection to a height equal to that reached with the slopes and lengths in Table 4-14 and 4-15.

Table 4-14. Dimensions of take-off climb surface – runways with operations of aeroplanes with a mass up to 5 700 kg

Aeroplane design group	I	IIA-IIB	IICa	III <sup>a</sup>	$\mathbf{IV}^{\mathbf{a}}$	Va
Distance from runway end <sup>b</sup>	30 m	60 m	-	-	-	-
Length of inner edge	60 m	80 m	-	-	-	-
Divergence (each side)	10%	10%	-	-	-	-
Final width	380 m	580 m	-	-	-	-
Length	1 600 m	2 500 m	-	-	-	-
Slope	5%	4%	-	-	-	-

a. Aeroplanes with a mass up to but not including 5 700 kg generally belong to aeroplane design groups I, IIA and IIB.

Table 4-15. Dimensions of take-off climb surface – runways with operations of aeroplanes with a mass above 5 700 kg

Aeroplane design group	I	IIA-IIB	ΙΙС	III	IV	V
Distance from TODA	-	-	-	-	-	-
Length of inner edge	144 m	156 m	156 m	172 m	180 m	180 m
Divergence (each side)	12.5%	12.5%	12.5%	12.5%	12.5%	12.5%
Final width	1 800 m <sup>a</sup>	$1~800~m^{a}$	$1\ 800\ m^{a}$	$1\ 800\ m^{a}$	$1~800~m^{\rm a}$	$1~800~m^{\rm a}$
Length	10 000 m	10 000 m	10 000 m	10 000 m	10 000 m	10 000 m
Slope	5%	4%	2%	2%	2%	2%

<sup>&</sup>lt;sup>a</sup> Where given operational conditions and performances are met, the final width can be decreased. Specifications concerning this reduction are contained in the *Airport Services Manual* (Doc 9137), Part 6.

b. The take-off climb surface starts at the end of the clearway if the clearway length exceeds the specified distance.




Figure 4-8 Take-off climb surface

## 4.4 Obstacle limitation requirements

## Obstacle free surfaces

4.4.1 Fixed objects shall not be permitted above the inner approach surface, inner transitional surfaces and balked landing surface and that complex surface extending between the lower edges of the inner transitional surfaces. Visual aids required for air navigation purposes or those objects required for aircraft safety purposes, and which must project into the airspace above the inner approach surface, inner transitional surfaces and balked landing surface or that complex surface extending between the lower edges of the inner transitional surfaces are permitted.

Note.— Specifications concerning objects required for aircraft safety purposes are provided in the Airport Services Manual (Doc 9137), Part 6 – Control of Obstacles. Such objects may for example consist of arresting systems, arresting cables, arresting beds, FOD detection systems, wildlife hazard equipment.

- 4.4.2 Visual aids required for air navigation purposes or those fixed objects required for aircraft safety purposes and which project into the airspace above the inner approach surface, inner transitional surfaces and balked landing surface or that complex surface extending between the lower edges of the inner transitional surfaces shall be frangible and mounted as low as possible.
- 4.4.3 Mobile objects shall not be permitted above the inner approach surface, inner transitional surfaces, balked landing surface and that complex surface extending between the lower edges of the inner transitional surfaces during the use of the runway for landing.
- 4.4.4 New objects or extensions of existing objects shall not be permitted above the approach surface and transitional surfaces and the complex surface extending between the lower edges of the transitional surfaces. Equipment and installations required for air navigation or for aircraft safety purposes, and which must project into the airspace above the approach surface and transitional surfaces or that complex surface extending between the lower edges of the transitional surfaces are permitted.
- 4.4.5 Equipment and installations required for air navigation or for aircraft safety purposes and which must project into the airspace above the approach surface and transitional surfaces or that complex surface extending between the lower edges of the transitional surfaces shall be frangible and mounted as low as possible.
- 4.4.6 Existing obstacles above the approach surface, and transitional surfaces or that complex surface extending between the lower edges of the transitional surfaces shall as far as practicable be removed.
- 4.4.7 Existing terrain and/or obstacles that cannot be removed and penetrate the approach surface and transitional surfaces or that complex surface extending between the lower edges of the transitional surfaces are only permitted when, after aeronautical study, it is determined that the obstacles do not adversely affect the safety or significantly affect the regularity of operations of aeroplanes.

Note.— Detailed specifications concerning aeronautical study are provided in PANS-Aerodromes (Doc 9981), Part II, Chapter 10.

## Obstacle evaluation surfaces

4.4.8 Obstacles penetrating the obstacle evaluation surfaces are only permitted when, after aeronautical study, it is determined that the obstacles do not adversely affect the safety or significantly affect the regularity of the existing and intended operations of aeroplanes.

Note.— Detailed specifications concerning aeronautical study is given in PANS-Aerodromes

## 4.5 Obstacle limitation surfaces requirements

Note 1.— The requirements for obstacle free surfaces are specified on the basis of the intended use of a runway and are intended to be applied when such use is made of the runway.

Note 2.— The requirements for obstacle evaluation surfaces are specified on the basis of the intended use and/or intended operations on the runway. When different obstacle evaluation surfaces overlap each other, each individual surface must be considered as they have specific functions.

#### 4.5.1 Obstacle free surfaces

- 4.5.1.1 The following obstacle free surfaces shall be established for a non-instrument or non-precision approach runway:
- a) approach surface;
- b) transitional surfaces;
- c) inner approach surface; and
- d) inner transitional surfaces.
- 4.5.1.2 The following obstacle free surfaces shall be established for a precision approach runway:
- a) Approach surface;
- b) transitional surfaces;
- c) inner approach surface;
- d) inner transitional surfaces; and
- e) balked landing surface.

## 4.5.2 Obstacle evaluation surfaces

- 4.5.2.1 The following obstacle evaluation surfaces shall be established:
- a) in case of circling approach and/or visual circuits the horizontal surface specified in 4.3.2 or a specific OES;
- b) in case of straight-in instrument approaches other than precision approaches, where the horizontal surface is not established the surface for straight-in instrument approaches specified in 4.3.3 or a specific OES;
- c) in case of precision approach procedure the surface for precision approaches specified in 4.3.4 or a specific OES;
- d) in case of instrument departure procedure the instrument departure surface specified in 4.3.5 or a specific OES;
- e) in case of take-off operations the take-off climb surface specified in 4.3.6 or a specific OES;

f) in case of operations different from the above — specific OES.

Note 1.— Operations mentioned in f) may include curved approach, VFR circuit patterns, etc.

Note 2.— Specifications and further guidance related to specific OES are contained in PANS-Aerodromes (Doc 9981) and in the Airport Services Manual (Doc 9137), Part 6—Control of Obstacles."

- 4.6 Objects outside the obstacle free surfaces and obstacle evaluation surfaces
- 4.6.1 In areas beyond the limits of the obstacle limitation surfaces, at least those objects which extend to a height of 100 m or more above ground elevation should be regarded as obstacles, unless an aeronautical study indicates that they do not constitute a hazard to the operations of intended aeroplane.

End of new text.		
	End of new text.	

## As applicable from 27 Nov'2025

- 4.7 Demolition of obstacles
- 4.7.1 Approval for the allowable height must be obtained from CAAB for the obstacles/structure within a radius of 15000m centred the aerodrome reference point and obstacles/structure beyond 15000m which extends to a height of more than 150m.
- 4.7.2 Any construction made or obstacle created in violation of the provisions of this ANO shall be demolished or removed at the expense of the owner or, as the case may be, the person responsible for creation of such obstacle.
- 4.8 Exception
- 4.8.1 Within the overlapping areas of the airspace of Hazrat Shahjalal International Airport and Tejgaon Airport, Dhaka, the admissible height of any construction shall be controlled by the Obstruction Limitation Surfaces (OLS) of Hazrat Shahjalal International Airport, Dhaka, leaving 1.8 KM from Tejgaon runway central line on the east".

## CHAPTER 5. VISUAL AIDS FOR NAVIGATION

Note: Sections 5.2.4.1; 5.2.16.3;5.2.16.4 & 5.2.16.9 modified; Section 5.2.4.2 deleted; Sections 5.2.4.3 to 5.2.4.10 have been renumbered as 5.2.4.2 to 5.2.4.9 respectively. Art 5.2.8.7 has been renumbered as 5.2.8.6

. . .

5.2 Markings

. . .

5.2.4 Threshold marking

## Application

5.2.4.1 A threshold marking shall be provided at the threshold of a paved instrument runway, and of a paved non-instrument runway where the code number is 3 or 4 and the runway is intended for use by international commercial air transport.

5.2.4.2 A threshold marking shall be provided at the threshold of a paved non-instrument runway where the code number is 3 or 4 and the runway is intended for use by other than international commercial air transport.

Editorial Note.— Renumber subsequent paragraphs.

. . .

#### Location

5.2.8.7 6 On a straight section of a taxiway the taxiway centre line marking shall be located along the taxiway centre line. On a taxiway curve the marking shall continue from the straight portion of the taxiway at a constant distance from the outside edge of the curve.

Note.— See 3.9.5 and Figure 3-2.

5.2.16 Mandatory instruction marking

• • •

#### Location

5.2.16.3 The mandatory instruction marking on taxiways where the eode letter is A, B, C or D OMGWS is up to but not including 9 m shall be located across the taxiway equally placed about the taxiway centre line and on the holding side of the runway-holding position marking as shown in Figure 5-10 (A). The distance between the nearest edge of the marking and the runway-holding position marking or the taxiway centre line marking shall be not less than 1 m.

. . .

5.2.16.4 The mandatory instruction marking on taxiways where the code letter is E or F OMGWS from 9 m up to but not including 15 m shall be located on both sides of the taxiway centre line marking and on the holding side of the runway-holding position marking as shown in Figure 5-10 (B). The distance between the nearest edge of the marking and the runway-holding position marking or the taxiway centre line marking shall be not less than 1 m.

• • •

#### **Characteristics**

5.2.16.9 The character height shall be 4 m for inscriptions where the code letter is C, D, E or F OMGWS is from 6 m up to but not including 15 m, and 2 m where the code letter is A or B OMGWS is up to but not including 6 m. The inscriptions should be in the form and proportions shown in Appendix 3.

• • •

## 5.3 Lights

Note of 5.3.1; Sections 5.3.12.5; 5.3.15.1; 5.3.17.1,5.3.17.2, 5.3.17.4, 5.3.17.9, 5.3.17.10, 5.3.17.13, 5.3.17.15; 5.3.17.20: 5.3.19.1; 5.3.21.1; Note of section 5.3.25.1; and Sections 5.3.25.6; 5.3.28.1& 5.3.28.2 have been modified.

Section 5.3.15.2 has been inserted after Art 5.3.15.1.

#### 5.3.1 General

• • •

# Light intensity and control

— on intensity. Guidance on maintenance criteria for aeronautical ground lights and on the Note.— In dusk or poor visibility conditions by day, lighting can be more effective than marking. For lights to be effective in such conditions or in poor visibility by night, they must be of adequate intensity. To obtain the required intensity, it will usually be necessary to make the light directional, in which case the arcs over which the light shows will have to be adequate and so orientated as to meet the operational requirements. The runway lighting system will have to be considered as a whole, to ensure that the relative light intensities are suitably matched to the same end and are maintained over time. (See Attachment A, Section 15, and use of a site standard is contained in the Aerodrome Design Manual (Doc 9157), Part 4).

• • •

# 5.3.12 Runway centre line lights

. . .

#### Location

5.3.12.5 Runway centre line lights shall be located along the centre line of the runway, except that the lights may be uniformly offset to the same side of the runway centre line by not more than 60 cm where it is not practicable to locate them along the centre line. The lights shall be located from the threshold to the end at longitudinal spacing of approximately 15 m. Where the serviceability level of the runway centre line lights specified as maintenance objectives in 10.5.7 or 10.5.11, as appropriate, can be demonstrated and the runway is—intended for use in runway visual range conditions of 350 300 m or greater, the longitudinal spacing may be approximately 30 m.

• • •

#### 5.3.15 Rapid exit taxiway indicator lights

• • •

#### Application

5.3.15.1 Rapid exit taxiway indicator lights shall be provided on a runway intended for use in runway visual range conditions less than a value of 350-300 m and/or where the traffic density is heavy.

. . .

5.3.15.2 Rapid exit taxiway indicator lights shall not be displayed in the event of any lamp failure or other failure that prevents the display of the light pattern depicted in Figure 5-25, in full.

## 5.3.17 Taxiway centre line lights

# Application

- 5.3.17.1 Taxiway centre line lights shall be provided on an exit taxiway, taxiway, de-icing/anti-icing facility and apron intended for use in runway visual range conditions less than a value of 350 m 300 m in such a manner as to provide continuous guidance between the runway centre line and aircraft stands, except that these lights need not be provided where the traffic density is light and taxiway edge lights and centre line marking provide adequate guidance.
- 5.3.17.2 Taxiway centre line lights shall be provided on a taxiway intended foruse at night in runway visual range conditions of 350 300 m or greater, and particularly on complex taxiway intersections and exit taxiways, except that these lights need not be provided where the traffic density is light and taxiway edge lights and centre line marking provide adequate guidance.

. . .

5.3.17.4 Taxiway centre line lights shall be provided on a runway forming part of a standard taxi-route and intended for taxiing in runway visual range conditions less than a value of 350 300 m, except that these lights need not be provided where the traffic density is light and taxiway edge lights and centre line marking provide adequate guidance.

• • •

- 5.3.17.9 Taxiway centre line lights shall be in accordance with the specifications of:
- a) Appendix 2, Figure A2-12, A2-13, or A2-14, for taxiways intended for use in runway visual range conditions of less than a value of 350-300 m; and
- b) Appendix 2, Figure A2-15 or A2-16, for other taxiways.
- 5.3.17.10 Where higher intensities are required, from an operational point of view, taxiway centre line lights on rapid exit taxiways intended for use in runway visual range conditions less than a value of 350 300 m shall be in accordance with the specifications of Appendix 2, Figure A2 -12. The number of levels of brilliancy settings for these lights shall be the same as that for the runway centre line lights.

• • •

## Taxiway centre line lights on taxiways

#### Location

5.3.17.13 Taxiway centre line lights on a straight section of a taxiway shall be spaced at longitudinal intervals of not more than 30 m, except that:

• • •

c) on a taxiway intended for use in RVR conditions of less than a value of 350 300 m, the longitudinal spacing should not exceed 15 m.

• • •

- 5.3.17.15 On a taxiway intended for use in RVR conditions of less than a value of 350 300 m, the lights on-a curve shall not exceed a spacing of 15 m, and on a curve of less than 400 m radius the lights should be spaced at intervals of not greater than 7.5 m. This spacing should extend for 60 m before and after the curve.
- Note 1.— Spacings on curves that have been found suitable for a taxiway intended for use in RVR conditions of 350-300 m or greater are:

Curve radius	Light spacing
up to 400 m	7.5 m
401 m to 899 m	15 m
900 m or greater	30 m.

• • •

## Taxiway centre line lights on runways

## Location

5.3.17.20 Taxiway centre line lights on a runway forming part of a standard taxi-route and intended for taxiing in runway visual range conditions less than a value of  $\frac{350}{300}$  m shall be spaced at longitudinal intervals not exceeding 15 m.

• • •

# Runway turn pad lights

#### Application

5.3.19.1 Runway turn pad lights shall be provided for continuous guidance on a runway turn pad intended for use in runway visual range conditions less than a value of 350-300 m, to enable an aeroplane to complete a 180-degree turn and align with the runway centre line.

## 5.3.21 Intermediate holding position lights

. . .

# Application

5.3.21.1 Except where a stop bar has been installed, intermediate holding position lights shall be provided at an intermediate holding position intended for use in runway visual range conditions less than a value of 350 300 m.

• • •

## 5.3.25 Visual docking guidance system

# Application

5.3.25.1 A visual docking guidance system shall be provided when it is intended to indicate, by a visual aid, the precise positioning of an aircraft on an aircraft stand and other alternative means, such as marshallers, are not practicable.

Note.— The factors to be considered in evaluating the need for a visual docking guidance system are in particular: the number and type(s) of aircraft using the aircraft stand, weather conditions, space available on the apron and the precision required for manoeuvring into the parking position due to aircraft servicing installation, passenger loading bridges, etc. See the Aerodrome Design Manual (Doc 9157), Part 4 — Visual Aids for guidance on the selection of suitable systems.

#### **Characteristics**

• • •

5.3.25.6 The accuracy of the system shall be adequate for the type of loading passenger boarding bridge and fixed aircraft servicing installations with which it is to be used.

. . .

#### 5.3.28 Road-holding position light

# Application

- 5.3.28.1 A road-holding position light shall be provided at each road-holding position serving a runway when it is intended that the runway will be used in runway visual range conditions less than a value of 350-300 m.
- 5.3.28.2 A road-holding position light shall be provided at each road-holding position serving a runway when it is intended that the runway will be used in runway visual range conditions of values between 350 m and 550 m.

## 5.4 Signs

Note: 5.4.1.3; 5.4.1.4 and Figure 5-15 modified; New Note 2 inserted after 5.4.3 and new text inserted after 5.4.7.5; Figures 5-7 and 5-10 have been replaced with new figures.

#### 5.4.1 General

### **Characteristics**

- 5.4.1.3 Signs shall be frangible. Those located near a runway or taxiway shall be sufficiently low to preserve clearance for propellers and the engine pods of jet aircraft. The installed height of the sign shall not exceed the dimension shown in the appropriate column of Table 5-5-, except for runway distance remaining signs (see 5.4.8).
- 5.4.1.4 Signs-Mandatory instruction signs and information signs shall be rectangular, as shown in Figures 5-30 and 5-31 with the longer side horizontal.

## 5.4.3 Information signs

Note 1.— See Figure 5-31 for pictorial representations of information signs.

Note 2.— See Chapter 7, 7.4.3 for specifications related to unserviceability signs providing information on operational restrictions and construction works at aerodromes.

. . .

New text inserted as follows: after 5.4.7.5

# 5.4.8 Runway distance remaining signs

- Note 1.— The inclusion of detailed specifications for runway distance remaining signs (RDRS) in this section is not intended to imply that an RDRS has to be provided. Attachment A, Section 23, provides guidance on the need to provide RDRSs. Guidance on installing RDRSs is given in the Aerodrome Design Manual (Doc 9157), Part 4.
- Note 2.— Runway excursions may take place in all visibility or weather conditions. The use of RDRS can form part of effective runway excursion prevention measures. The purpose of RDRSs is to provide pilots with distance-to-go information to the extremity of the runway, to enhance situational awareness and enable pilots to decide whether to commence a go-around or to apply braking action for more efficient rollout and runway exit speeds. It is essential that pilots operating at aerodromes with RDRS be familiar with the purpose of these signs.
- Note 3.— Provisions related to the identification of hazards and management of safety risks, including the need for safety risk assessment related to runway safety, is available in PANS-Aerodromes (Doc 9981), Chapter 8.

#### Location

- 5.4.8.1 Where provided, runway distance remaining signs (RDRS) shall be placed along the full length of the runway at longitudinal spacing of approximately 300 m, parallel and equidistant from the runway centre line.
- Note.— Displaced threshold areas that are used for take-off and/or roll-out are treated as part of the runway for purposes of locating the signs.
- 5.4.8.2 Runway distance remaining signs shall be placed outside the edges of the runway at a distance shown in Table 5-6.

## **Characteristics**

- 5.4.8.3 Where provided, an RDRS shall consist of an inscription in white on a black background.
- 5.4.8.4 The installed height of the RDRS shall not exceed the dimension shown in the appropriate column of Table 5-6. All RDRSs on one runway shall be the same size.

Table 5-6. Location distances for runway distance remaining signs

	Sign height	(mm)	Perpendicular distance from		
Code number	Legend	Face (min.)	Installed (max.)	defined runway pavement edge to near side of sign	
1 or 2	640	760	1070	6 - 10.5 m	
3 or 4	1000	1200	1520	15 - 22.5 m	
3 or 4	1200	1500	1600	25 m or more	

• • • •




Figure 5-7. Enhanced taxiway centre line marking




Figure 5-10. Mandatory instruction marking




Figure 5-15. Inner 300 m approach and runway lighting for precision approach runways, categories II and III, where the serviceability levels of the lights specified as maintenance objectives in Chapter 10 can be demonstrated

Sections 5.5.2 to 5.5.8 renumbered as 5.5.1 to 5.5.7; subsequent sub articles have also been renumbered accordingly.

#### 5.5 Markers

5.5.<del>2</del> 1 General

Markers shall be frangible. Those located near a runway or taxiway shall be sufficiently low to preserve clearance for propellers and for the engine pods of jet aircraft.

Note 1.— Anchors or chains, to prevent markers which have broken from their mounting from blowing away, are sometimes used.

Note 2.— Guidance on frangibility of markers is given in the Aerodrome Design Manual (Doc 9157), Part 6.

5.5.3 2 Unpaved runway edge markers

## Application

5.5.3 2.1 Markers shall be provided when the extent of an unpaved runway is not clearly indicated by the appearance of its surface compared with that of the surrounding ground.

5.5.3 2.2 Where runway lights are provided, the markers shall be incorporated in the light fixtures. Where there are no lights, markers of flat rectangular or conical shape shall be placed so as to delimit the runway clearly. Characteristics

5.5.3—2.3 The flat rectangular markers shall have a minimum size of 1 m by 3 m as far as practicable and shall be placed with their long dimension parallel to the runway centre line. The conical markers shall have a height not exceeding 50 cm.

5.5.4 3 Stopway edge markers Application

5.5.4—3.1 Stopway edge markers shall normally be provided when the extent of a stopway is not clearly indicated by its appearance compared with that of the surrounding ground. Characteristics

5.5.4 3.2 The stopway edge markers shall be sufficiently different from any runway edge markers used to ensure that the two types of markers cannot be confused.

Note.— Markers consisting of small vertical boards camouflaged on the reverse side, as viewed from the runway, have proved operationally acceptable.

5.5.<del>5</del> 4 Kept Intentionally vacant.

5.5.6 5 Taxiway edge markers

## Application

5.5.6 5.1 Taxiway edge markers shall be provided on a taxiway where the code number is 1 or 2 and taxiway centre line or edge lights or taxiway centre line markers are not provided.

Location

5.5.6 5.2 Where p rovided Taxiway edge markers shall be installed at least at the same locations as would the taxiway edge lights had they been used.

Characteristics

- 5.5.6 5.3 A taxiway edge marker shall be retro reflective blue.
- 5.5.6. 5.4 The marked surface as viewed by the pilot shall be a rectangle and should have a minimum viewing area of 150 cm<sup>2</sup>.
- 5.5.6 5.5 Taxiway edge markers shall be frangible. Their height shall be sufficiently low to preserve clearance for propellers and for the engine pods of jet aircraft.
- 5.5.7 6 Kept Intentionally vacant
- 5.5.8 7 Kept Intentionally vacant

# CHAPTER 6. VISUAL AIDS FOR DENOTING OBSTACLES

Section 6.2.2.8 has been modified.

# 6.2 Marking and/or lighting of objects

6.2.2 Mobile objects

• • •

Lighting

. . .

6.2.2.8 Low-intensity obstacle lights on objects with limited mobility such as passenger boarding aerobridges shall be fixed-red, and as a minimum be in accordance with the specifications for low-intensity obstacle lights, Type A, in Table 6-1. The intensity of the lights shall be sufficient to ensure conspicuity considering the intensity of the adjacent lights and the general levels of illumination against which they would normally be viewed.

#### CHAPTER 7. VISUAL AIDS FOR DENOTING RESTRICTED USE AREAS

Sections 7.1.5 to 7.1.7 have been relocated under new Section 7.1.1 with modifications; sections 7.1.1 to 7.1.4 have been relocated below a new section 7.1.2 with modifications; Sections 7.1.1 to 7.1.4 have been duplicated & relocated under new section 7.1.3 with modifications; Figure 7-1 relocated below 7.1.3.4 & Note 2; Section 7.1.4 with new heading and sub-sections 7.1.4.1 to 7.1.4.3 & Table 1-7; new Figure 7-2 and then sections 7.1.4.4 to 7.1.4.6 have been inserted. Existing Figure 7-2 to be read as Figure 7-3.

## 7.1 Closed runways and taxiways or parts thereof

## 7.1.1 General

Editorial Note.— Relocate sections 7.1.5 to 7.1.7 under new 7.1.1 with modifications as indicated below.

- 7.1.57.1.1.1 When a runway or taxiway or portion thereof is permanently closed, all normal runway and taxiway markings shall be obliterated.
- 7.1.67.1.1.2 Lighting on systems provided for a closed runway or taxiway or portion thereof shall not be operated, except as required for maintenance purposes.
  - *Note.*—*Lighting systems provided for a runway include both approach and runway lighting systems.*
- 7.1.77.1.1.3 In addition to closed markings, as specified in 7.1.2 and 7.1.3, when the a closed runway or taxiway or portion thereof is intercepted by ausable runway or taxiway which is can be used at night, unserviceability lights shall be placed across the entrance to the closed area at intervals not exceeding 3 m (see 7.4.4-2).

## 7.1.2 Closed runway marking

Editorial Note.— Relocate sections 7.1.1 to 7.1.4 below as new 7.1.2 with modifications as indicated.

## Application

- 7.1.17.1.2.1 A closed runway marking shall be displayed on a runway or taxiway or portion thereof which is permanently closed to the use of all aircraft.
- 7.1.27.1.2.2 A closed runway marking shall be displayed on a temporarily closed runway<del>or taxiway</del> or portion thereof, except that such marking may be omitted when the closing is of short duration and adequate warning by air traffic services is provided.

#### Location

7.1.37.1.2.3 On a runway a A closed runway marking shall be placed at eachend extremity of the runway, or portion thereof, declared closed, and additional markings shall be so placed that the maximum interval between markings does not exceed 300 m. On a taxiway a closed marking shall be placed at each end of the taxiway or portion thereof closed.

#### **Characteristics**

- 7.1.47.1.2.4 The closed runway marking shall be white and of the form and proportions as detailed in Figure 7-1, Illustration a), when displayed on a runway, and shall be of the form and proportions as detailed in Figure 7-1, Illustration b), when displayed on a taxiway. The marking shall be white when displayed on a runway and shall be yellow when displayed on a taxiway.
- Note 1.— When an area is temporarily closed, frangible barriers or markings utilizing materials other than paint or other suitable means may be used to identify the closed area.
- Note 2. Procedures pertaining to the planning, coordination, monitoring and safety management of works in progress on the movement area are specified in the PANS-Aerodromes (Doc 9981).

#### 7.1.3 Closed taxiway marking

Editorial Note.— Duplicate and relocate sections 7.1.1 to 7.1.4 under new 7.1.3 with modifications as indicated.

## **Application**

- 7.1.17.1.3.1 A closed taxiway marking shall be displayed on a runway or taxiway or portion thereof which is permanently closed to the use of all aircraft.
- 7.1.27.1.3.2 A closed taxiway marking shall be displayed on a temporarily closed runway or taxiway or portion thereof, except that such marking may be omitted when the closing is of short duration and adequate warning by air traffic services is provided.

#### Location

7.1.37.1.3.3 On a runway a closed marking shall be placed at each end of the runway, or portion thereof, declared closed, and additional markings shall be so placed that the maximum interval between markings does not exceed 300 m. On a A closed taxiway a closed marking shall be placed at least at each endextremity of the taxiway or portion thereof closed.

#### **Characteristics**

- 7.1.47.1.3.4 The closed taxiway marking shall be yellow and of the form and proportions as detailed in Figure 7-1, Illustration ab)., when displayed on a taxiway. The marking shall be white when displayed on a runway and shall be yellow when displayed on a taxiway.
- Note 1.— When an area is temporarily closed, frangible barriers or markings utilizing materials other than paint or other suitable means may be used to identify the closed area.
- Note 2.— Procedures pertaining to the planning, coordination, monitoring and safety management of works in progress on the movement area are specified in the PANS-Aerodromes (Doc 9981).

*Editorial Note.*— *Relocate* Figure 7-1 below 7.1.3.4, Note 2.

## 7.1.4 Closed runway lighting

# Application

- 7.1.4.1 Where operationally desirable, at an aerodrome provided with runway lighting, closed runway lighting shall be provided on runway (s) that are temporarily closed or temporarily restricted for take-off.
- Note 1.— The purpose of the closed runway lighting is to reduce the likelihood of unintended landings during periods of poor visibility or at night whenever the runway lighting must be switched on for electrical maintenance.
  - Note 2.— In dusk or poor visibility conditions by day, lighting can be more effective than markings.
- Note 3.— The closed runway lighting is intended to be controlled either automatically or manually by air traffic services or by the aerodrome operator.

#### Location

- 7.1.4.2 A closed runway lighting shall be placed on the centre line near each extremity of the runway temporarily declared closed.
- Note.— Placement of a closed runway lighting would enhance the situational awareness of the runway closure to the pilot.

#### Characteristics


7.1.4.3 The closed runway lighting as viewed by the pilot shall be of the equivalent elevated form and proportions as detailed in Figure 7-2, showing a minimum of five lights uniformly spaced on each branch, with a minimum interval as specified by Table 7-1.

Table 7-1. Minimum interval between closed runway lights centres

Number of lights per branch	Minimum interval between lights centres
5	1.5 m
7	1.0 m
9	0.8 m

Note 1.— The closed runway lighting may be either fixed or mobile.

Note 2.— The fixed closed runway lighting may be formed as if shadowed (i.e. stretched) from the equivalent elevated structure (see Appendix 3, Note 3). Guidance on the sizing of a fixed closed runway lighting is given in the Aerodrome Design Manual (Doc 9157), Part 4.






Figure 7-2. Example of equivalent elevated closed runway lighting with five lights per branch

Editorial Note.— Renumber subsequent figures as needed. (Fig 7-2 re-numbered as Fig 7-3)

- 7.1.4.4 Closed runway lights shall show flashing variable white in the direction of approach to the runway, at a rate of one second on and one second off.
- 7.1.4.5 Closed runway lights shall automatically revert to fixed lights in the event of the flashing system failure.
- 7.1.4.6 Closed runway lights shall be in accordance with the specifications in Appendix 2, Figure A2-27.

New text under Section 7.4.1 (Subsection 7.4.1.1 to 7.4.1.6); deleting the existing section 7.4.3, a new section 7.4.3 with sub-sections 7.4.3.1 to 7.4.3.13 and a new section 7.4.4 with sub-sections 7.4.4.1 to 7.4.4.3 have been inserted.

Existing sections 7.4.1, 7.4.2 & 7.4.4 renumbered as 7.4.2.1 to 7.4.2.3 respectively. and existing sections 7.4.5 to 7.4.7 have been renumbered as 7.4.4.4 to 7.4.4.6 respectfully.

7.4 Unserviceable areas
Insert new text as follows:
7.4.1Unserviceability markings
Application
7.4.1.1 Where operationally required, unserviceability signs should be supplemented by unserviceability markings on the surface of the pavement.
7.4.1.2 Where it is impracticable to install an unserviceability sign in accordance with 7.4.3.1, an unserviceability marking shall be provided on the surface of the pavement.
Location
7.4.1.3 Unserviceability markings shall be displayed across the surface of the taxiway or apron where necessary and positioned so as to be legible from the cockpit of an approaching aircraft.
Characteristics
7.4.1.4 Unserviceability markings shall consist of an inscription in black upon an orange background.
7.4.1.5 The inscriptions shall be in the form and proportions shown in Appendix 3.
7.4.1.6 The background shall be rectangular and extend a minimum of 0.5 m laterally and vertically beyond the extremities of the inscription.
End of new text.

7.4 Unserviceable areas

Editorial Note.— Relocate Section 7.4 under new 7.4.2, with modifications.

## 7.4.2Unserviceability lights

# Application

- 7.4.1 7.4.2.1 Unserviceability<del>markers</del> lights shall be<del>displayed</del> provided on a movement area used at night, wherever any portion of a taxiway, apron or holding bay the movement area is unfit for the movement of aircraft but it is still possible for aircraft to bypass the area safely. On a movement area used at night, unserviceability lights shall be used.
- Note 1.— Unserviceability markers and lights are used for such purposes as warning pilots of a hole in a taxiway or apron pavement or outlining a portion of pavement, such as on an apron, that is under repair. They are not suitable for use when a portion of a runway becomes unserviceable, nor on a taxiway when a major portion of the width becomes unserviceable. In such instances, the runway or taxiway is normally closed.
- Note 2.— Procedures pertaining to the planning, coordination, monitoring and safety management of works in progress on the movement area are specified in the PANS-Aerodromes (Doc 9981).

#### Location

- 7.4.1 7.4.2.2 Unserviceability<del>markers and</del> lights shall be placed at intervals sufficiently close so as to delineate the unserviceable area.
  - Note.— Guidance on the location of unserviceability lights is given in Attachment A, Section 13.

#### Characteristics of unserviceability markers

7.4.2 Unserviceability markers shall consist of conspicuous upstanding devices such as flags, cones or marker boards.

#### Characteristics of unserviceability lights

7.4.3 7.4.2.3 An unserviceability light shall consist of a red fixed light. The light shall have an intensity sufficient to ensure conspicuity considering the intensity of the adjacent lights and the general level of illumination against which it would normally be viewed. In no case shall the intensity be less than 10 cd of red light.

## *Insert* new text as follows:

# 7.4.3 Unserviceability signs

- Note 1.— Temporary changes to the movement area may include, inter alia, reduction in the runway length, reduction in the maximum allowable wingspan, taxiway closure or any other closure to the movement area. Unserviceability signs provide relevant information to aerodrome users to maintain an acceptable level of safety during aircraft and vehicle operations, by reducing the risk of confusion and enhancing the awareness of such temporary changes.
- Note 2.— Unserviceability signs can be used to indicate temporary closed or restricted areas, as well as to provide information on operational restrictions to aerodrome users.

# Application

- 7.4.3.1 Unserviceability signs shall be provided where there is an operational need to indicate temporary changes to runway declared distances.
- 7.4.3.2 Unserviceability signs shall be provided where there is an operational need to indicate temporary changes to taxiways and aprons.
- 7.4.3.3 Existing signs shall be removed or obscured at an aerodrome if they provide inadequate or misleading information regarding unserviceability areas.
- 7.4.3.4 The information provided by unserviceability signs shall not be in conflict with the information provided by the appropriate aeronautical information services.

Note .— The information provided by unserviceability signs supplements that which is provided by the appropriate aeronautical information services unit.

## Location

- 7.4.3.5 Unserviceability signs shall be located where operationally needed on the movement area. The location distances on the manoeuvring area shall be as per taxiing guidance signs in Table 5-5.
- 7.4.3.6 The location of unserviceability signs shall not visually obscure or provide conflicting information with existing operationally required visual aids.

#### **Characteristics**

- 7.4.3.7 Unserviceability signs shall be frangible. Those located near a runway or taxiway shall be sufficiently low to preserve clearance for propellers and the engine pods of jet aircraft. The installed height of unserviceability signs shall not exceed the dimension for taxiing guidance signs shown in Table 5-5.
- 7.4.3.8 Unserviceability signs shall be rectangular, as shown in Figure 7-3, with the longer side horizontal.
- 7.4.3.9 The inscriptions on an unserviceability sign shall be in accordance with the provisions of Appendix 4.
- 7.4.3.10 Unserviceability signs shall consist of an inscription in black on an orange background. Unserviceability signs shall be supplemented by a black outline measuring 10 mm in width for runways where the code number is 1 or 2, and 20 mm in width for runways where the code number is 3 or 4.
- 7.4.3.11 The inscription on an unserviceability sign shall consist of a legible, clear and simple message, only providing the useful and necessary information for the safety of the operation.
- *Note. See Figure 7-3 for examples of unserviceability signs.*
- 7.4.3.12 Unserviceability signs shall be retroreflective in accordance with the provisions of Appendix 4.
- 7.4.3.13 Where there is a need to enhance the conspicuity of unserviceability signs, they should be supplemented by two red or yellow simultaneously flashing lights. The intensity and the beam spread of these lights should be in accordance with the specifications in Appendix 2, Figure A2-24.




Figure 7-3. Examples of unserviceability signs

## 7.4.4 Unserviceability markers

# **Application**

7.4.4.1 Unserviceability markers shall be displayed wherever any portion of a taxiway, apron or holding bay is unfit for the movement of aircraft but it is still possible for aircraft to bypass the area safely.

Note.— Unserviceability markers are used for such purposes as warning pilots of a hole in a taxiway or apron pavement or outlining a portion of pavement, such as on an apron, that is under repair. They are not suitable for use when a portion of a runway becomes unserviceable, nor on a taxiway when a major portion of the width becomes unserviceable. In such instances, the runway or taxiway is normally closed.

#### Location

7.4.4.2 Unserviceability markers shall be placed at intervals sufficiently close, so as to delineate the unserviceable area.

## **Characteristics**

7.4.4.3 Unserviceability markers shall consist of conspicuous upstanding devices such as flags, cones or marker boards.

End of new text.

# Characteristics of unserviceability cones

7.4.4 An unserviceability cone shall be at least 0.5 m in height and red, orange or yellow or any one of these colours in combination with white.

# Characteristics of unserviceability flags

7.4.6 7.4.4.5 An unserviceability flag shall be at least 0.5 m square and red, orange or yellow or any one of these colours in combination with white.

# Characteristics of unserviceability marker boards

7.4.7 7.4.4.6 An unserviceability marker board shall be at least 0.5 m in height and 0.9 m in length, with alternate red and white or orange and white vertical stripes.

# CHAPTER 8. ELECTRICAL SYSTEMS

Section 8.1.10 has been modified and a new provision 8.2.4 has been inserted.

## 8.1 Electrical power supply systems for air navigation facilities

···
Visual aids

Application
···

8.1.10 The following aerodrome facilities shall be provided with a secondary power supply capable of supplying power when there is a failure of the primary power supply:

. . .

- c) approach, runway and taxiway lighting as specified in 8.1.6 to 8.1.9;
- d) closed runway lighting, if provided in accordance with 7.1.4.1 and connected to the primary power supply;
- de) meteorological equipment;
- *ef*) essential security lighting, if provided in accordance with 9.11;
- fg) essential equipment and facilities for the aerodrome responding emergency agencies;
- gh) floodlighting on a designated isolated aircraft parking position if provided in accordance with 5.3.24.1; and
- hi) illumination of apron areas over which passengers may walk.

Note.— Specifications for secondary power supply for radio navigation aids and ground elements of communications systems are given in Annex 10, Volume I, Chapter 2.

#### 8.2 System design

. . .

8.2.4 The electrical systems for the power supply and the control of the closed runway lighting shall be so designed that the closed runway lighting system is operated independently of runway lighting systems.

# CHAPTER 9. AERODROME OPERATIONAL SERVICES, EQUIPMENT AND INSTALLATIONS

Note 1 of Section 9.1.3; Section 9.2.13: Text deleted and new text inserted; Art 9.2.15 deleted; Articles from 9.2.16 to 9.2.46 renumbered as 9.2.15 to 9.2.45; Sections 9.6 & 9.6.1 have been modified. New provisions 9.5.5 to 9.5.7, 9.5.10, 9.5.12 to 9.5.14 have been inserted; Provisions 9.5.5, 9.5.6, 9.5.7 have been renumbered as 9.5.8, 9.5.9 & 9.5.11 respectfully. New provisions 9.7.1 & 9.7.2 applicable as of 26 November 2026 have been inserted and provisions 9.7.1 to 9.7.5 to be renumbered as 9.7.3 to 9.7.7 respectively.

# 9.1 Aerodrome emergency planning

#### General

. . .

9.1.3 The plan shall coordinate the response or participation of all existing agencies which, in the opinion of the appropriate authority, could be of assistance in responding to an emergency.

Note 1.— Examples of agencies are:

 on the aerodrome: air traffic control units, rescue and firefighting services, aerodrome administration, medical and ambulance services, aircraft operators, ground handling service providers, security services, and police;

. . .

## 9.2 General Rescue and firefighting

9.2.12 At aerodromes where operations by aeroplanes larger than the average size in a given category are planned, the quantities of water shall be recalculated and the amount of water for foam production and the discharge rates for foam solution shall be increased accordingly.

Note.—Guidance on the determination of quantities of water and discharge rates based on the largest theoretical aeroplane in a given category is available in Chapter 2 of the Airport Services Manual (Doc 9137), Part 1.

9.2.13 At aerodromes where operations by aeroplanes larger than the average size in a given category are planned, the quantities of water shall be recalculated and the amount of water for foam production and the discharge ratesfor foam solution shall be increased accordingly.

Note. Guidance on the determination of quantities of water and discharge rates based on the largest overall length of aeroplane in a given category is available in Chapter 2 of the Airport Services Manual (Doc 9137), Part-1.

9.2.13 The quantity of foam concentrates separately provided on vehicles for foam production shall be in proportion to the quantity of water provided and the foam concentrate selected.

Table 9-2. Minimum usable amounts of extinguishing agents

		meeting nce level A	Foam meeting leve		Foam meeting leve		Complement	ary agents
Aerodrome		Discharge rate foam solution/ minute	Water	Discharge rate foam solution/ minute	Water	Discharge rate foam solution/ minute	Dry chemical powders	Discharge Rate (kg/second)
category	(L)	(L)	(L)	(L)	(L)	(L)	(kg)	
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(9)
1	350	350	230	230	160	160	45	2.25
2	1 000	800	670	550	460	360	90	2.25
3	1 800	1 300	1 200	900	820	630	135	2.25
4	3 600	2 600	2 400	1 800	1 700	1 100	135	2.25
5	8 100	4 500	5 400	3 000	3 900	2 200	180	2.25
6	11 800	6 000	7 900	4 000	5 800	2 900	225	2.25
7	18 200	7 900	12 100	5 300	8 800	3 800	225	2.25
8	27 300	10 800	18 200	7 200	12 800	5 100	450	4.5
9	36 400	13 500	24 300	9 000	17 100	6 300	450	4.5
10	48 200	16 600	32 300	11 200	22 800	7 900	450	4.5

Note.— The quantities of water shown in columns 2, 4 and 6 are based on the average overall length of aeroplanes in a given category.

9.2.14 The amount of foam concentrate provided on a vehicle shall be sufficient to produce at least two loads of foam solution.

9.2.15 The amount of foam concentrate provided on a vehicle shall be sufficient to produce at least two loads of foam solution.

- 9.2.<del>16</del> 15 Supplementary water supplies, for the expeditious replenishment of rescue and firefighting vehicles at the scene of an aircraft accident, should be provided.
- 9.2.17 16 When a combination of different performance level foams are provided at an aerodrome, the total amount of water to be provided for foam production shall be calculated for each foam type and the distribution of these quantities shall be documented for each vehicle and applied to the overall rescue and firefighting requirement.
- 9.2.<del>18</del> 17 The discharge rate of the foam solution shall not be less than the rates shown in Table 9-2.
- 9.2.<del>19</del> 18 The complementary agents shall comply with the appropriate specifications of the International Organization for Standardization (ISO).

Note—specifications are available in ISO Publication 7202 (Powder).

- 9.2.20 19 The discharge rate of complementary agents shall be no less than the values shown in Table 9-2.
- 9.2.<del>21</del> 20-Dry chemical powders shall only be substituted with an agent that has equivalent or better firefighting capabilities for all types of fires where complementary agent is expected to be used.

Note.—Guidance on the use of complementary agents can be found in the Airport Services Manual (Doc 9137),

Part 1.

9.2.<del>22</del> 21 A reserve supply of foam concentrate, equivalent to 200 percent of the quantities identified in Table 9-2, shall be maintained normally on the aerodrome for vehicle replenishment purposes.

Note.—Foam concentrate carried on fire vehicles in excess of the quantity identified in Table 9-2 can contribute to the reserve.

- 9.2.23 22 A reserve supply of complementary agent, equivalent to 100 per cent of the quantity identified in Table 9-2, shall be maintained normally on the aerodrome for vehicle replenishment purposes. Sufficient propellant gas shall be included to utilize this reserve complementary agent.
- 9.2.24 23 Category 1 and 2 aerodromes that have replaced up to 100 per cent of the water with complementary agent shall normally hold a reserve supply of complementary agent of 200 percent.
- 9.2.25 24 Where a major delay in the replenishment of the supplies is anticipated, the amount of reserve supply in 9.2.22, 9.2.23 and 9.2.24 is to be increased as determined by a risk assessment.

Note.—For guidance on the conduct of a risk analysis to determine the quantities of reserve extinguishing agents is available in Airport Services Manual (Doc 9137), Part 1.

Rescue equipment

9.2.<del>26</del> 25 Rescue equipment commensurate with the level of aircraft operations is to be provided on the rescue and firefighting vehicle(s).

Note.—Guidance on the rescue equipment to be provided at an aerodrome is given in the Airport Services Manual (Doc 9137), Part 1.

Response time

- 9.2.<del>27</del> 26 The operational objective of the rescue and firefighting service shall be to achieve a response time not exceeding three minutes, where practicable two minutes to any point of each operational runway, in optimum visibility and surface conditions.
- 9.2.<del>28</del> 27 Kept Intestinally vacant.
- 9.2.<del>29</del> 28 The operational objective of the rescue and firefighting service should be to achieve a response time not exceeding three minutes to any other part of the movement area, in optimum visibility and surface conditions.
- Note 1.— Response time is considered to be the time between the initial call to the rescue and firefighting service, and the time when the first responding vehicle(s) is (are) in position to apply foam at a rate of at least 50 per cent of the discharge rate specified in Table 9-2.
- Note 2.—Optimum visibility and surface conditions are defined as daytime, good visibility, no precipitation with normal response route free of surface contamination, e.g. water, ice or snow.
- 9.2.30 29 To meet the operational objective as nearly as possible in less than optimum conditions of visibility, especially during low visibility operations, suitable guidance, equipment and/or procedures as appropriate for rescue and firefighting services shall be provided.

Note.—Additional guidance is available in the Services Manual (Doc 9137), Part 1.

- 9.2.31 30 Any vehicles, other than the first responding vehicle(s), required to deliver the amounts of extinguishing agents specified in Table 9-2 shall ensure continuous agent application and shall arrive no more than four minutes where practicable three minutes from the initial call.
- 9.2.32 31 Any vehicles, other than the first responding vehicles(s), required to deliver the amounts of extinguishing agents specified in Table 9-2 is to ensure continuous agent application and should arrive where practicable three minutes from the initial call.
- 9.2.33 32 A system of preventive maintenance of rescue and firefighting vehicles should be employed to ensure effectiveness of the equipment and compliance with the specified response time throughout the life of the vehicle. Emergency access roads

9.2.34 33 Emergency access roads should be provided on an aerodrome where terrain conditions permit their construction, so as to facilitate achieving minimum response times. Particular attention should be given to the provision of ready access to approach areas up to 1 000 m from the threshold, or at least within the aerodrome boundary. Where a fence is provided, the need for convenient access to outside areas should be taken into account.

Note.— Aerodrome service roads may serve as emergency access roads when they are suitably located and constructed.

- 9.2.35 34 Emergency access roads shall be capable of supporting the heaviest vehicles which will use them, and be usable in all weather conditions. Roads within 90 m of a runway shall be surfaced to prevent surface erosion and the transfer of debris to the runway. Sufficient vertical clearance should be provided from overhead obstructions for the largest vehicles.
- 9.2.<del>36</del> 35 When the surface of the road is indistinguishable from the surrounding area, or in areas where snow may obscure the location of the roads, edge markers is to be placed at intervals of about 10 m. Fire stations
- 9.2.37 36 All rescue and firefighting vehicles shall normally be housed in a fire station. Satellite fire stations if necessary should be provided whenever the response time cannot be achieved from a single fire station.
- 9.2.38 37 The fire station shall normally be located so that the access for rescue and firefighting vehicles into the runway area is direct and clear, requiring a minimum number of turns.

  Communication and alerting systems

9.2.39 38 A discrete communication system shall normally be provided linking a fire station with the control tower, any other fire station on the aerodrome and the rescue and firefighting vehicles.

- 9.2.40 39 An alerting system for rescue and firefighting personnel, capable of being operated from that station, shall normally be provided at a fire station, any other fire station on the aerodrome and the aerodrome control tower. Number of rescue and firefighting vehicles
- 9.2.41 40 The minimum number of rescue and firefighting vehicles provided at an aerodrome shall be in accordance with the following tabulation:

Aerodrome category	Rescue and firefighting vehicles
1	1
2	1
3	1
4	1
5	1
6	2
7	2
8	3
9	3
10	3

#### Personnel

- 9.2.42 41 All rescue and firefighting personnel shall be properly trained to perform their duties in an efficient manner and shall participate in live fire drills commensurate with the types of aircraft and type of rescue and firefighting equipment in use at the aerodrome, including pressure-fed fuel fires.
- Note 1. Guidance to assist the aerodrome operator in providing proper training is given in Attachment A, Section 18 of Annex 14 Vol 1, and the Airport Services Manual (Doc 9137), Part 1.
- Note 2. Fires associated with fuel discharged under very high pressure from a ruptured fuel tank are known as "pressure-fed fuel fires".
- 9.2.43 42 The rescue and firefighting personnel training programme shall include training in human performance, including team coordination.
- Note.— Guidance material to design training programmes on human performance and team coordination can be found in the Human Factors Training Manual (Doc 9683).
- 9.2.44 43 During flight operations, sufficient trained and competent personnel shall be designated to be readily available to ride the rescue and firefighting vehicles and to operate the equipment at maximum capacity. These personnel shall be deployed in a way that ensures that minimum response times can be achieved and that continuous agent application at the appropriate rate can be fully maintained. Consideration should also be given for personnel to use hand lines, ladders and other rescue and firefighting equipment normally associated with aircraft rescue and firefighting operations.
- 9.2.45 44 The minimum number of rescue and firefighting personnel required, shall be determined by completing task resource analysis and the level of staffing, so determined shall be documented in the Aerodrome Manual.

Note.— Guidance on the use of a task resource analysis can be found in the Airport Services Manual (Doc 9137), Part 1.

9.2.46 45 All responding rescue and firefighting personnel shall be provided with protective clothing and respiratory equipment to enable them to perform their duties in an effective manner.

#### 9.5 Apron management service

- 9.5.5 Aircraft should be allocated to an aircraft stand or apron area appropriate to the aircraft characteristics.
- 9.5.6 A risk assessment should be carried out if there is a need to allocate aircraft parking to areas other than aircraft stands or apron areas.
- Note .—The need to allocate aircraft to other areas could arise from situations such as mass diversions, special events, adverse weather conditions, contingency requirements, work in progress, etc..
- 9.5.7 When allocating an aircraft to an aircraft stand, the following parameters should be considered:
  - a) parking aids;
  - b) facilities serving the aircraft stand;
  - c) proximity of infrastructure;
  - *d) other parked aircraft in the neighbouring aircraft stands;*

- e) aircraft stand dependencies; and
- f) jet blast and propeller wash related protection.

## **Apron Safety**

- 9.5.5 9.5.8 An emergency vehicle responding to an emergency shall be given priority over all other surface movement traffic.
  - 9.5.6 9.5.9 A vehicle operating on an apron shall:

. . .

- 9.5.10 Aircraft shall be guided while arriving on or departing from the aircraft stand.
- Note.— Means for guidance can be a visual docking guidance systems, personnel, lighting or markings.
- 9.5.711 An aircraft stand shall be visually monitored in-person or remotely to ensure that the recommended clearance distances are provided to an aircraft using the stand maintained.
- Note.— Stand dependencies may occur when multiple centre lines are used on the same stand, creating possible variations in fixed or mobile obstacle separations with adjacent stands.
- 9.5.12 Emergency stop procedures shall be in place to stop an aircraft when entering the stand if the safety of operations on the aircraft stand is compromised.
- Note.— Procedures on the training of operational personnel, and on apron safety and operations, are specified in the PANS-Aerodromes (Doc 9981), Part II, Chapters 1 and 7.
- 9.5.13 Personnel, other than those required to assist the initial arrival and departure of the aircraft, shall not be allowed to approach the aircraft when anti-collision lights are turned on and engines are running.
  - *Note. This does not apply to helicopter operations as per Annex 6, Part 3.*
  - 9.5.14 Parked aircraft shall be appropriately secured to prevent any unintended movement.

. . .

## 9.6 Ground servicing of aircraft Aircraft fuelling – Safety considerations

- 9.6.1 Fire extinguishing equipment suitable for at least initial intervention in the event of a fuel fire and personnel trained in its use shall be readily available during the ground servicing of an aircraft fuelling operations, and there shall be a means of quickly summoning the rescue and firefighting service in the event of a fire or major fuel spill.
- 9.6.2 When aircraft refuelling operations take place while passengers are embarking, on board or disembarking, ground equipment shall be positioned so as to allow:
  - a) the use of a sufficient number of exits for expeditious evacuation; and
  - b) a ready escape route from each of the exits to be used in an emergency.

c)

## 9.7 Ground handling

## (Applicable as of 26 November 2026)

- Note 1.— Ground handling can be provided by an aircraft operator, an aerodrome operator or an independent organization. When provided by an aircraft operator or an aerodrome operator, this organization is also considered, as a ground handling service provider (GHSP).
- *Note* 2.— *A list of ground handling services is provided in the* Manual on Ground Handling (Doc 10121), *Appendix B*.
  - 9.7.1 Member, Flight Standard and Regulation shall regularly assess the impact of ground handling operations on aviation safety.
- Note.— Guidance on the assessment of the impact of ground handling operations on aviation safety is provided in the Manual on Ground Handling (Doc 10121), Chapter 2.
- 9.7.2. Member, Flight Standard and Regulation should establish criteria for the safety oversight of ground handling as part of their State Safety Programme (SSP).
- Note 1.— Guidance on the establishment of criteria for the safety oversight of ground handling, and approaches for safety oversight are contained in the Manual on Ground Handling (Doc 10121)
- Note 2.— Provisions on periodically reviewing the need to extend SMS to additional aviation sectors are contained in Annex 19 Safety Management. Examples of additional aviation sectors can include GHSP.

Editorial Note.— S ubsequent paragraphs 9.7.1 to 9.7.5 to be renumbered as 9.7.3 to 9.7.7 respectively.

• • •

# CHAPTER 10. AERODROME MAINTENANCE

## Section 10.2.10 renumbered as 10.2.9; Sections 10.5.1, 10.5.8 & 10.5.9 have been modified

and a new note after section 10.5.1 has been inserted.

#### 10.2 Pavement

10.2.<del>10</del> 9 When a taxiway is used by turbine-engined aeroplanes, the surface of the taxiway shoulders shall be maintained so as to be free of any loose stones or other objects that could be ingested by the aeroplane engines. Note.—Guidance on this subject is given in the Aerodrome Design Manual (Doc 9157), Part 2.

. . .

#### 10.5 Visual aids

. . .

10.5.1 A light shall be deemed to be unserviceable when the main beam average intensity is less than 50 per cent of the value specified in the appropriate figure in Appendix 2. For light units where the designed main beam average intensity is above the value shown in Appendix 2, the 50 per cent value shall be related to that design value. For light units where the main beam average intensity is required to be higher than the value specified in the appropriate figure in Appendix 2, a light shall be deemed to be unserviceable when the main beam average intensity value is less than 50 per cent of this higher value and not the value specified in Appendix 2.

Note.— Guidance on maintenance criteria for aeronautical ground lights, on the use of a site standard and on using a higher main beam average intensity is contained in the Aerodrome Design Manual (Doc 9157), Part 4.

. . .

- 10.5.8 The system of preventive maintenance employed for a stop bar provided at a runway-holding position used in conjunction with a runway intended for operations in runway visual range conditions less than a value of 350-300 m shall have the following objectives:
  - a) no more than two lights will remain unserviceable; and
  - b) two adjacent lights will not remain unserviceable unless the light spacing is significantly less than that specified.
- 10.5.9 The system of preventive maintenance employed for a taxiway intended for use in runway visual range conditions less than a value of  $\frac{350}{300}$  m shall have as its objective that no two adjacent taxiway centre line lights be unserviceable.

#### APPENDIX 2. AERONAUTICAL GROUND LIGHT CHARACTERISTICS

Sl. No 4 after Figure A 2-11 has been modified. A new Figure A 2-27 has been inserted; as such collective note has been modified as follows .-. . . See collective notes for Figures A2-1 to A2-11, and A2-26 and A2-27. 1. Figure A2-1. Isocandela diagram for approach centre line light and crossbars (white light) 4. See collective notes for Figures A2-1 to A2-11, and A2-26 and A2-27. Figure A2-2. Isocandela diagram for approach side row light (red light) 3. See collective notes for Figures A2-1 to A2-11, and A2-26 and A2-27. Figure A2-3. Isocandela diagram for threshold light (green light) . . . See collective notes for Figures A2-1 to A2-11, and A2-26 and A2-27. 3. Figure A2-4. Isocandela diagram for threshold wing bar light (green light) 3. See collective notes for Figures A2-1 to A2-11, and A2-26 and A2-27. Figure A2-5. Isocandela diagram for touchdown zone light (white light) See collective notes for Figures A2-1 to A2-11, and A2-26 and A2-27. 4. Figure A2-6. Isocandela diagram for runway centre line light with 30 m longitudinal spacing (white light) and rapid exit taxiway indicator light (yellow light) See collective notes for Figures A2-1 to A2-11, and A2-26 and A2-27. 4. Isocandela diagram for runway centre line light with 15 m longitudinal spacing Figure A2-7. (white light) and rapid exit taxiway indicator light (yellow light) 2. See collective notes for Figures A2-1 to A2-11, and A2-26 and A2-27. Figure A2-8. Isocandela diagram for runway end light (red light) 5. See collective notes for Figures A2-1 to A2-11, and A2-26 and A2-27.

Figure A2-9. Isocandela diagram for runway edge light where width of runway is 45 m (white light)

• • •

5. See collective notes for Figures A2-1 to A2-11, and A2-26 and A2-27.

Figure A2-10. Isocandela diagram for runway edge light where width of runway is 60 m (white light)

• • •

Collective notes to Figures A2-1 to A2-11, and A2-26 and A2-27

. . .

- 4. Average intensity ratio. The ratio between the average intensity within the ellipse defining the main beam of a typical new light and the average light intensity of the main beam of a new runway edge light shall be as follows:
- 4. The average intensity within the ellipse defining the main beam of a new light is established as a ratio of the minimum (1.0) average intensity of a new Runway edge light. The ratios also define the maximum allowed main beam average intensity for the lights in the lighting system supporting runway operations. Guidance on maintenance criteria for aeronautical ground lights and the use of a site standard is contained in the *Aerodrome Design Manual* (Doc 9157), Part 4.

Figure A2-1	Approach centre line and crossbars	1.5 to 2.0 2.0 to 3.0 (white light)
•••		
Figure A2-9	Runway edge (45 m runway width)	1.0 to 1.5 (white light)
Figure A2-10	Runway edge (60 m runway width)	1.0 to 1.5 (white light)

. . .

Figure A2-12. Isocandela diagram for taxiway centre line (15 m spacing), RELs, no-entry bar and stop bar lights in straight sections intended for use in runway visual range conditions of less than a value of 350-300 m where large offsets can occur and for low-intensity runway guard lights,

Configuration B

. . .

igure A2-13. Isocandela diagram for taxiway centre line (15 m spacing), no-entry bar and stop bar lights in straight sections intended for use in runway visual range conditions of less than a value of 350-300 m

•

Figure A2-14. Isocandela diagram for taxiway centre line (7.5 m spacing), RELs, no-entry bar and stop bar lights in curved sections intended for use in runway visual range conditions of less than a value of 350-300 m

. . .

Figure A2-15. Isocandela diagram for taxiway centre line (30 m, 60 m spacing), no-entry bar and stop bar lights in straight sections intended for use in runway visual range conditions of 350-300 m or greater

• • •


Figure A2-16. Isocandela diagram for taxiway centre line (7.5 m, 15 m, 30 m spacing), no-entry bar and stop bar lights in curved sections intended for use in runway visual range conditions of 350-300 m or greater

. .

...Figure A2-24. Isocandela diagram for each light in low-intensity runway guard lights, Configuration A and for flashing lights supplementing unserviceability signs

2. See collective notes for Figures A2-1 to A2-11, and A2-26 and A2-27.

Figure A2-26. Isocandela diagram for take-off and hold lights (THL) (red light)



# Notes:

$$\frac{x^2}{a^2} + \frac{y^2}{b^2} = 1$$

a	10	15
b	10	15

- 2. N is the total number of lights of the closed runway lighting.
- 3. See collective notes for Figures A2-1 to A2-11, A2-26 and A2-27.

Figure A2-27. Isocandela diagram for closed runway lights (white light)

# APPENDIX 4. REQUIREMENTS CONCERNING DESIGN OF TAXHING GUIDANCE SIGNS

Caption of Appendix 4 has been modified. Provisions 9 &11 have been modified, a new note under provision 9 & a new provision 12 and a new Figure A 4-5 have been inserted and Existing provisions numbering 12 & 13 have been re-numbered as 13 & 14 respectively in Appendix 4 of ANO 14 VOL-I.

Note.—See Chapter 5, Section 5.4, for specifications on the application, location and characteristics of signs.

. . .

9. The forms of characters, i.e. letters, numbers, arrows and symbols for mandatory instruction and information signs, shall conform to those shown in Figure A4-2. The width of characters and the space between individual characters shall be determined as indicated in Table A4-1.

Note.— Guidance on the width of characters and the space between individual characters for RDRS is contained in the Aerodrome Design Manual (Doc 9157), Part 4 — Visual Aids.

. . .

11. The face width of mandatory instruction and information signs shall be determined using Figure A4-4 except that, where a mandatory instruction sign is provided on one side of a taxiway only, the face width shall not be less than:

. . .


- 12. The face width of runway distance remaining sign (RDRS) shall be determined using Figure A4-5.
- 123. Borders

. . .

134. The colours of signs shall be in accordance with the appropriate specifications in Appendix 1.

• • •

## Editorial Note.— Insert new Figure A4-5



Explanatory Note to Figure A4-5: "H" stands for the inscription height.

Figure A4-5. Sign dimensions for RDRS